

BR

BALANCE
RAIL

USER MANUAL























SWAROVSKI
OPTIK







Swarovski-Optik AG & Co KG.
6067 Absam, Austria
Tel. 00800/32425056
customerservice@swarovskioptik.com
SWAROVSKIOPTIK.COM

BA-702-28, 10/2025




ATX/STX 85/95
BTX 85/95
ATS/STS 65/80




AS

ATX/STX 115






ATX/STX 85/95
BTX 85/95/115
ATS/STS 65/80





STANDARD

ATX/STX/BTX 85/95
ATS/STS 65/80





BR + ME 1.7x




BTX 115


ATX/STX 115






- 1 ATS 65/80 + SOC
- 2 STS 65/80 + SOC
- 3 STS 65/80
- 4 ATS 65/80
BTX
ATX/STX/BTX + SOC
- 5 ATX/STX
ATX/STX 115 + SOC
- 6 ATX/STX/BTX + ME 1.7x
ATX/STX/BTX + ME 1.7x + SOC
ATX/STX 115




ATX/STX/BTX 65



ATX/STX/BTX 65



ATX/STX 115



AS/STANDARD

ATX/STX 85/95
BTX 85/95/115
ATS/STS 65/80

ATX/STX 65/115
BTX 65

