

Rue Coffee Table

Assembly Instructions

URBAN OUTFITTERS


NO ADDITIONAL TOOLS REQUIRED.

WARNINGS:


Do not throw away packing materials and carton until after assembly.
Ensure all parts are present prior to assembly.
Contact customer service immediately if parts are missing
Assemble all parts on a clean smooth surface.

CARE INSTRUCTIONS:


Avoid direct exposure to sunlight.
Blot spills with a clean, white cloth; do not rub.
Do not use harsh chemicals.
Before cleaning any part, test a small spot in a hidden area.
Do not place over heat or air conditioning vents.
Do not over-tighten the parts.
The parts may loosen after initial use; re-tighten as necessary.



PARTS INCLUDED:



(A)Top



(B) Base x3



(C) Bolts
[0.75" x 1" DJ x9
or
[19mm X 25 mm] x9



(D) Allen Key

Rue Coffee Table

Assembly Instructions

URBAN OUTFITTERS

STEP 1

Place the top upside down. Align the legs (B) with the bottom of the top (A) matching the holes in each. Insert the bolts (C) and partially tighten each bolt (C). Once all the bolts (C) are partially tightened, fully tighten the bolts (C). Flip the assembled table upright to complete assembly.

