

Tara Console Table

URBAN OUTFITTERS

Assembly Instructions


NO ADDITIONAL TOOLS REQUIRED

WARNINGS:


Do not throw away packing materials and carton until after assembly.
Ensure all parts are present prior to assembly.
Contact customer service immediately if parts are missing.
Assemble all parts on a clean smooth surface.

CARE INSTRUCTIONS:


Avoid direct exposure to sunlight.
Do not place over heat or air conditioning vents.
Adjust levelers so that the furniture sits flat on uneven floors.
Blot spills with a clean white cloth, do not rub.
Do not use harsh chemicals.
Before cleaning any part test a small spot in a hidden area.
You may need to re-tighten all bolts after initial use.




PARTS INCLUDED:




1) Top Panel
(48 x 15 x 0.7") x 1
or
(121.9 x 38.1 x 1.8cm)



2) Bottom
(48 x 15 x 1.8") x 1
or
(121.9 x 38.1 x 4.5cm)



3) Leg
(14 x 12.5 x 1.5") x 1
or
(35.6 x 31.8 x 3.8 cm)



4) Legs
(14 x 12.5 x 3.5") x 2
or
(35.6 x 31.8 x 8.8 cm)



A) Bolt
(D 0.47 / 0.24 x 1.38") x 6
or
(D 12 / 6 x 35 mm)



B) Spring Washer
(D 0.47 / 0.24 x 0.08") x 6
or
(D 12 / 6 x 2 mm)



C) Flat Washer
(D 0.63 / 0.24 x 0.08") x 6
or
(D 16 / 6 x 2 mm)



D) Allen Key
(D 0.16 x 2.32") x 1
or
(D 4 x 59 mm)



E) Bolt
(D 0.47 / 0.24 x 0.59") x 8
or
(D 12 / 6 x 15 mm)


Tara Console Table

URBAN OUTFITTERS

Assembly Instructions


STEP 1

Attach the top panel (1) to legs (3)&(4) with bolts (E) and Allen key (D) as shown. **Do not over-tighten!**



STEP 2

Attach the bottom (2) to the legs (3), (4) with bolts (A), flat washer (C), and spring washer (B) using Allen key (D) as shown.



STEP 3

With help, flip the furniture upright.

