

Chuck Nightstand

Assembly Instructions

URBAN OUTFITTERS

TOOLS REQUIRED BUT NOT INCLUDED:

Phillips head screwdriver

WARNINGS:

Do not throw away packing materials and carton until after assembly.

Ensure all parts are present prior to assembly.

Contact customer service immediately if parts are missing.

Assemble all parts on a clean smooth surface.

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.

Do not place over heat or air conditioning vents.


Adjust levelers so that the furniture sits flat on uneven floors.

Blot spills with a clean white cloth, do not rub.


Do not use harsh chemicals.

Before cleaning any part test a small spot in a hidden area.

You may need to re-tighten all bolts after initial use.



PARTS INCLUDED:



(A) Nightstand
x1



(B) Leg
x4



(C) Drawer pull
x1


Chuck Nightstand

Assembly Instructions

URBAN OUTFITTERS

STEP 1

Lay the parts out onto a clean smooth surface such as carpet or cardboard. Screw the legs (B) into the nightstand (A) clockwise until tight. With help stand the nightstand upright making sure you do not lean it on its legs.



STEP 2

Unscrew the drawer pull (C) from the inside of the drawer with a philips head screwdriver (not included). Then, re-attach the drawer pull (C) to the front of the drawer as shown below. Do not over tighten. Turn the adjustable feet so the dresser sits flat on the ground.

