

Mikaela Three Tier Wide Shelf

URBAN OUTFITTERS

Assembly Instructions

TOOLS REQUIRED BUT NOT INCLUDED:


Phillips head screwdriver, Drill , Hammer, Pencil

WARNINGS:


Do not throw away packing materials and carton until after assembly. Ensure all parts are present prior to assembly. Contact customer service immediately if parts are missing. Assemble all parts on a clean smooth surface. Anti-Tip Hardware must be in place to ensure safety from tipping.

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.
Do not place over heat or air conditioning vents.
Adjust levelers so that the furniture sits flat on uneven floors.
Blot spills with a clean white cloth, do not rub.
Do not use harsh chemicals.
Before cleaning any part test a small spot in a hidden area.
You may need to re-tighten all bolts after initial use.




PARTS INCLUDED:




Mikaela Three Tier Wide Shelf

Assembly Instructions


URBAN OUTFITTERS




① X1




② X1



③ X2



④ X1



⑤ X4




(A) Bolt
[M6x10mm] x12pcs



(B) Bolt
[M4x8mm] x18pcs




(C) Adjustable Foot
x4pcs



(D) Screw
[M4x40mm] x2 sets



(E) Metal Plate
x2pcs




(F) Hex Key
x1pc

Mikaela Three Tier Wide Shelf

URBAN OUTFITTERS

Assembly Instructions

STEP 1




Mikaela Three Tier Wide Shelf

URBAN OUTFITTERS

Assembly Instructions

STEP 2




Mikaela Three Tier Wide Shelf

URBAN OUTFITTERS


Assembly Instructions

STEP 3



STEP 4

Anti-Tip Hardware



The included hardware is intended for attachment to drywall or wooden wall surfaces, contact your local hardware store to find the correct anchor for alternative wall-types such as stone or brick.