

NO ADDITIONAL TOOLS REQUIRED

### WARNINGS:

Do not discard packing materials and the carton until assembly is complete.

Ensure all parts are present prior to assembly.

Contact customer service immediately if parts are missing.

Assemble all parts on a clean smooth surface.

**Use a MAX 4W LED Type T4 / G9 bulb.**

**Do not use bulb that exceeds recommended wattage.**

### CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.

Blot spills with a clean, white cloth; do not rub.

Do not use harsh chemicals.

Before cleaning any part, test a small spot in a hidden area.

Do not over-tighten the parts.

The parts may loosen after initial use; re-tighten as necessary.




### PARTS INCLUDED:



(A) Anchors X2



(B) Mounting Plate




(C) Canopy Screws  
[5/32-32T\*15mmL] X3



(D) Screws  
[M4x25mm] X2



(E) Lamp Body



(F) Glass Shade

### STEP 1

As you unpack and prepare for assembly, place the contents on a carpeted or padded flat surface area.

### STEP 2

Place the sconce on the wall in its desired location and mark the location on the wall.

Wood or Stud installation:

Insert Screws (D) through mounting plate (B). Then, use a phillips head screwdriver to fasten the screws directly into the wall at the marked location.

Drywall installation:

Insert anchors (A) into the wall at the marked locations. Insert Screws (D) through mounting plate (B) and into the anchors, then tighten with a phillips head screwdriver (not included).

**The included hardware is intended for attachment to drywall or wooden wall surfaces, contact your local hardware store to find the correct anchor for alternative wall-types such as stone or brick.**

### STEP 3

Place the Lamp Body (E) on the Mounting Plate (B), aligning the holes on the Lamp Body (E) with the holes in the Mounting Plate (B). Insert the Canopy Screws (C) and tighten to secure the Lamp Body (E) in place.

### STEP 4

Insert the specified light bulb into the socket. DO NOT EXCEED THE SPECIFIED WATTAGE.

### STEP 5

Screw the Glass Shade (F) onto the Lamp body (E). DO NOT OVERTIGHTEN!

### STEP 6

Plug the lamp into an outlet, and use the switch attached to the chord to turn the lamp on and off.

**Use a MAX 4W LED Type T4 / G9 bulb. DO NOT USE A BULB THAT EXCEEDS THE SPECIFIED WATTAGE.**

