Paula Pendant

URBAN OUTFITTERS

Assembly Instructions

NO ADDITIONAL TOOLS REQUIRED

WARNINGS:

Do not discard packing materials and the carton until assembly is complete.

Ensure all parts are present prior to assembly.

Contact customer service immediately if any parts are missing.

Assemble all parts on a clean, smooth surface.

Use an E26 60W bulb, do not exceed the recommended wattage.

The paper shade is delicate, do not over-stretch!

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.


Blot spills with a clean, white cloth; do not rub.

Do not use harsh chemicals.

Before cleaning any part, test a small spot in a hidden area.

Do not over-tighten the parts.

The parts may loosen after initial use; re-tighten as necessary.



PARTS INCLUDED:







(A) Pipe / Chord

(B) Harp

(C) Paper Shade

Assembly Instructions


STEP 1

Unscrew the socket ring from the pipe / chord (A) then insert it through the harp (B). Screw the socket ring back onto the pipe / chord (A) to secure the harp (B). Carefully insert harp (B) through the paper shade (C). Insert the points at the top of the pipe / chord (A) into the rings at the top of the paper shade (C).



STEP 2

Carefully stretch and place the rings at the bottom of the paper shade (C) into the points at the bottom of the harp (B). Plug in your new lamp, and use the switch attached to the chord to turn it on and off.



STEP 3

The plastic tab on the chord can be used to hang the lamp as shown below. Contact your local hardware store to purchase the correct hardware for your ceiling and follow the hardware's mounting instructions to ensure safe installation.



EXCLUSIVE AND CONFIDENTIAL PROPERTY OF URBAN OUTFITTERS, INC.© 2017 UO, Inc. All rights reserved, including all applicable copyright, design and patent rights. Any unauthorized reproduction, adaptation, distribution or other infringement will be prosecuted.