

Clara Nightstand

URBAN OUTFITTERS

Assembly Instructions


NO ADDITIONAL TOOLS REQUIRED

WARNINGS:


Do not throw away packing materials and carton until after assembly.
Ensure all parts are present prior to assembly.
Contact customer service immediately if parts are missing.
Assemble all parts on a clean smooth surface.

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.
Do not place over heat or air conditioning vents.
Adjust levelers so that the furniture sits flat on uneven floors.
Blot spills with a clean white cloth, do not rub.
Do not use harsh chemicals.
Before cleaning any part test a small spot in a hidden area.
You may need to re-tighten all bolts after initial use.



PARTS INCLUDED



(A) Nightstand
x1



(B) Legs
x4



(C) Round head Allen bolt
[M6X 16MM] x16



(D) Washer
[M6X 20MM] x16



(E) Allen Key
[4MM] x1

Clara Nightstand

URBAN OUTFITTERS

Assembly Instructions

STEP 1

With help, lay the nightstand (A) over onto a clean smooth surface. Attach the legs (B) to the nightstand (A) with the Allen bolts (C) and flat washers (D) using the Allen key (E) as shown. Do not over-tighten the bolts. With help, flip the nightstand (A) back over onto its legs to complete assembly.

