

Rumi Coffee Table

Assembly Instructions

URBAN OUTFITTERS


NO ADDITIONAL TOOLS REQUIRED

WARNINGS:


Do not discard packing materials and the carton until assembly is complete.
Ensure all parts are present prior to assembly.
Contact customer service immediately if any parts are missing.
Assemble all parts on a clean, smooth surface.

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.
Blot spills with a clean, white cloth; do not rub.
Do not use harsh chemicals.
Before cleaning any part, test a small spot in a hidden area.
Do not place over heat or air conditioning vents.
Do not over-tighten the parts.
The parts may loosen after initial use; re-tighten as necessary.




PARTS INCLUDED:




(A) Table top
x1



(B) Leg
x4



(C) Hex key
x1



(D) Bolt
[1/4" x 1-1/2"] x16



(E) Spring washer
[1/4"] x16



(F) Flat washer
[1/4"] x16


Rumi Coffee Table

Assembly Instructions

URBAN OUTFITTERS

STEP 1

Place the table top (A) upside down and insert the legs (B). Insert flat washers (F), spring washers (E) and bolts (D). Tighten with supplied hex key (C). Do not over tighten.



STEP 2

Adjust the levelers as shown below to accommodate uneven floors.

