

# Anja Coffee Table

## Assembly Instructions

URBAN OUTFITTERS


NO ADDITIONAL TOOLS REQUIRED

### WARNINGS:


Do not throw away packing materials and carton until after assembly.  
Ensure all parts are present prior to assembly.  
Contact customer service immediately if parts are missing.  
Assemble all parts on a clean smooth surface.

### CARE INSTRUCTIONS:


Avoid direct exposure to sunlight.  
Do not place over heat or air conditioning vents.  
Adjust levelers so that the furniture sits flat on uneven floors.  
Blot spills with a clean white cloth, do not rub.  
Do not use harsh chemicals.  
Before cleaning any part test a small spot in a hidden area.  
You may need to re-tighten all bolts after initial use.




### PARTS INCLUDED:




(A) Table top  
x1




(B) Leg  
x1




(C) Leg  
x1



(D) Hex key  
x1



(E) Bolt  
[1/4" x 2-3/4"] x1



(F) Bolt  
[1/4" x 3/4"] x8



(G) Spring washer  
[1/4"] x9



(H) Flat washer  
[1/4"] x9


# Anja Coffee Table

## Assembly Instructions

URBAN OUTFITTERS

### STEP 1

With help flip the leg over onto a clean smooth surface such as carpet or cardboard. Align the leg (B) to table top (A) as shown. Insert flat washer (H), spring washer (G) and bolt (F). Tighten with supplied hex key (D). Do not over tighten.



### STEP 2

Align the leg (C) to the leg (B) and press firmly into place. Insert the flat washer (H), spring washer (G) and bolt (F). Tighten with supplied hex key (D). Locate the hole in the leg (C) and insert the flat washer (H), spring washer (G) and bolt (E). Tighten with supplied hex key (D). With help stand the table upright making sure you do not lean it on its legs.

