

GRACE TABLE LAMP

URBAN OUTFITTERS

Assembly Instructions


NO ADDITIONAL TOOLS REQUIRED

WARNINGS:

Do not throw away packing materials and carton until after assembly.
Ensure all parts are present prior to assembly.
Contact customer service immediately if parts are missing.
Assemble all parts on a clean smooth surface.
Use a 7W (MAX) Type A incandescent bulb or a 4.5W LED bulb.
Do not use bulb that exceeds recommended wattage.

CARE INSTRUCTIONS:


Avoid direct exposure to sunlight.
Do not place over heat or air conditioning vents.
Adjust levelers so that the furniture sits flat on uneven floors.
Blot spills with a clean white cloth, do not rub.
Do not use harsh chemicals.
Before cleaning any part test a small spot in a hidden area.
You may need to re-tighten all bolts after initial use.




PARTS INCLUDED:




(A) Finial



(B) Glass Shade



(C) Body



(D) Finish Washer

GRACE TABLE LAMP

Assembly Instructions

URBAN OUTFITTERS

STEP 1

As you unpack and prepare for assembly, place the contents on a clean carpeted or padded flat surface area.

STEP 2

Unscrew the Finial (A) from the Glass Shade (B) and remove the Glass Shade (B) and Finish Washer (D). Insert the specified bulb into the Socket.

STEP 3

Place the Glass Shade (B) and Finish Washer (D) onto the Body (C) and secure the Glass Shade (B) by screwing the Finial (A) clockwise onto the Body (C).

STEP 4

Plug the lamp into an outlet, turn on switch (E), and enjoy your new lamp

Use a 7W (MAX) Type A incandescent bulb or a 4.5W LED bulb. Do not use bulb that exceeds recommended wattage.

