

ARABELLA FLOOR LAMP

URBAN OUTFITTERS

Assembly Instructions

NO ADDITIONAL TOOLS REQUIRED

WARNINGS:

Do not discard packing materials and the carton until assembly is complete.

Ensure all parts are present prior to assembly.

Contact customer service immediately if any parts are missing.

Assemble all parts on a clean, smooth surface.

Use a MAX 60W Type A bulb.

Do not use a bulb that exceeds the specified wattage.

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.

Blot spills with a clean, white cloth; do not rub.

Do not use harsh chemicals.

Before cleaning any part, test a small spot in a hidden area.

Do not over-tighten the parts.

The parts may loosen after initial use; re-tighten as necessary.



PARTS INCLUDED:



(A) Socket Ring



(B) Lamp Shade




(C) Upper Pole



(D) Middle Pole



(E) Lower Pole



(F) Base

ARABELLA FLOOR LAMP

URBAN OUTFITTERS

Assembly Instructions

STEP 1

As you unpack and prepare for assembly, place the contents on a carpeted or padded flat surface area

STEP 2

Screw the Lower Pole (E) onto the Base (F) and pull excess cord from the Base (F).

STEP 3

Screw the Middle Pole (D) to the Lower Pole (E).

STEP 4

Screw the Upper Pole (C) to the Middle Pole (D).

STEP 5

Place the Lamp Shade (B) onto the Upper Pole (C) and secure it by screwing the Socket Ring (A) clockwise onto the Upper Pole (C).

STEP 6

Insert the specified light bulb into the socket. DO NOT EXCEED THE SPECIFIED WATTAGE.

STEP 7

Plug the lamp into an outlet, and use the switch attached to the chord to turn the lamp on and off.

Use a MAX 60W Type A bulb. DO NOT USE A BULB THAT EXCEEDS THE SPECIFIED WATTAGE!

