URBAN OUTFITTERS

Assembly Instructions

NO ADDITIONAL TOOLS REQUIRED

WARNINGS:

Do not throw away packing materials and carton until after assembly.

Ensure all parts are present prior to assembly.

Contact customer service immediately if parts are missing.

Assemble all parts on a clean smooth surface.

Use a MAX 25W Type G40 bulb.

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.

Do not place over heat or air conditioning vents.


Adjust levelers so that the furniture sits flat on uneven floors.

Blot spills with a clean white cloth, do not rub.

Do not use harsh chemicals.


Before cleaning any part test a small spot in a hidden area.

You may need to re-tighten all bolts after initial use.



PARTS INCLUDED:







(A) Lamp Body

(B) Lamp Shade

(C) Socket Ring

Assembly Instructions

STEP 1

As you unpack and prepare for assembly, place the contents on a carpeted or padded flat surface area.

STEP 2

Place the Lamp Shade (B) on the Lamp Body (A) then screw the Socket Ring (C) on the Lamp Body (A) clockwise until tight. Do not over-tighen the socket ring (C).

STEP 3

Insert the specified light bulb into the socket. DO NOT EXCEED THE SPECIFIED WATTAGE.

STEP 4

Plug into outlet, turn on switch, and enjoy your new lamp.

Use a MAX 25W Type G40 bulb. Do not use bulb that exceeds recommended wattage.

