

BERNIE TABLE LAMP

URBAN OUTFITTERS

Assembly Instructions

NO ADDITIONAL TOOLS REQUIRED

WARNINGS:

Do not discard packing materials and the carton until assembly is complete.

Ensure all parts are present prior to assembly.

Contact customer service immediately if any parts are missing.

Assemble all parts on a clean, smooth surface.

Use a 40W (MAX) Type A incandescent bulb or a 6W LED bulb.

Do not use bulb that exceeds recommended wattage.

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.

Blot spills with a clean, white cloth; do not rub.


Do not use harsh chemicals.

Before cleaning any part, test a small spot in a hidden area.


Do not over-tighten the parts.

The parts may loosen after initial use; re-tighten as necessary.


PARTS INCLUDED:



(A) Socket Ring



(B) Shade



(C) Body

BERNIE TABLE LAMP

URBAN OUTFITTERS

Assembly Instructions

STEP 1

As you unpack and prepare for assembly, place the contents on a clean carpeted or padded flat surface area.

STEP 2

Place the shade (B) onto the body (C) and secure it by screwing the socket ring (A) clockwise onto the body (C).

STEP 3

Screw a 40W (MAX) Type A incandescent bulb or a 6W LED bulb into the socket.

STEP 4

Plug the lamp into an outlet, turn on the switch, and enjoy your new lamp.

Use a 40W (MAX) Type A incandescent bulb or a 6W LED bulb. DO NOT USE A BULB THAT EXCEEDS THE SPECIFIED WATTAGE.

