URBAN OUTFITTERS

Assembly Instructions

NO ADDITIONAL TOOLS REQUIRED

WARNINGS:

Do not throw away packing materials and carton until after assembly.

Ensure all parts are present prior to assembly.

Contact customer service immediately if parts are missing.

Assemble all parts on a clean smooth surface.

Use a 7W (MAX) Type A incandescent bulb or a 7W LED bulb.

Do not use bulb that exceeds recommended wattage.

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.

Do not place over heat or air conditioning vents.


Adjust levelers so that the lamp sits flat on uneven floors.

Blot spills with a clean white cloth, do not rub.

Do not use harsh chemicals.

Before cleaning any part test a small spot in a hidden area.

You may need to re-tighten all bolts after initial use.



GRACE FLOOR LAMP

Assembly Instructions

URBAN OUTFITTERS

STEP 1

As you unpack and prepare for assembly, place the contents on a clean carpeted or padded flat surface area.

STEP 2

Screw a 7W (MAX) Type A incandescent bulb or a 7W LED bulb (not included) into the socket.

STEP 3

Plug the lamp into outlet, turn on switch (C), and enjoy your new lamp

Use a 7W (MAX) Type A incandescent bulb or a 7W LED bulb. Do not use bulb that exceeds recommended wattage.

