

WHITE CAT WITH GRASS

URBAN OUTFITTERS

Assembly Instructions

NO ADDITIONAL TOOLS REQUIRED

WARNINGS:

Do not discard packing materials and the carton until assembly is complete.

Ensure all parts are present prior to assembly.

Contact customer service immediately if parts are missing.

Assemble all parts on a clean smooth surface.

Use a MAX 25W Type G bulb.

Do not use bulb that exceeds recommended wattage.

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.


Blot spills with a clean, white cloth; do not rub.

Do not use harsh chemicals.


Before cleaning any part, test a small spot in a hidden area.

Do not over-tighten the parts.


The parts may loosen after initial use; re-tighten as necessary.



PARTS INCLUDED:



(A) Lamp Body



(B) Lamp Shade



(C) Socket Ring



(D) Glass

WHITE CAT WITH GRASS

Assembly Instructions

URBAN OUTFITTERS

STEP 1

As you unpack and prepare for assembly, place the contents on a carpeted or padded flat surface area.

STEP 2

Place the Lamp Shade (B) on the Lamp Body (A). Secure the shade by screwing the Socket Ring (C) onto the Lamp Body (A) clockwise until tight.

STEP 3

Put the Glass (D) next to the cat.

STEP 4

Insert the specified light bulb into the socket. DO NOT EXCEED THE SPECIFIED WATTAGE.

STEP 5

Plug the lamp into an outlet, turn on switch, and enjoy your lamp.

Use a MAX 25W Type G bulb. DO NOT USE A BULB THAT EXCEEDS THE SPECIFIED WATTAGE.

