

Meena Sofa

Assembly Instructions

URBAN OUTFITTERS

TOOLS REQUIRED BUT NOT INCLUDED:

(Not Applicable)

Do not throw away packing materials and carton until after assembly.
Assemble all parts on a clean smooth surface.

CARE INSTRUCTION:


Avoid direct exposure to sunlight. Do not place overheat or air conditioning vents. Adjust levelers so that the furniture sits flat on uneven floors.

Blot spills do not rub, with a clean white cloth.


Do not use harsh chemicals.

Before cleaning any part test a small spot in a hidden area.

You may need to re-tighten all bolts after initial use.



PARTS INCLUDED



(A) Leg
x5



(B) Bolt x5
[5/16x40mm]



(C) Flat Washer x5
[18mm]



(D) Wrench x1
[M5x100mm]



(E) Felt Pad
x5



(F) Spring Washer
x5


Meena Sofa

Assembly Instructions

URBAN OUTFITTERS

STEP 1

Lay the sofa on its back and locate the leg package attached to the bottom of the sofa. Remove parts and insert Bolts (B), Spring washers (F), and Flat washers (C) into the Legs (A) as shown.



STEP 2

Insert the Legs (A) with hardware into the holes on the bottom of the sofa. Tighten with Allen key (D). Cover hardware with Felt pads (E).

