

MARGOT MUTLTIHOOK RACK - LARGE

URBAN OUTFITTERS

Assembly Instructions

TOOLS REQUIRED BUT NOT INCLUDED:

Screwdriver, Drill, Hammer, Level, Pencil

WARNINGS:

Do not throw away packing materials and carton until after assembly.

Assemble all parts on a clean smooth surface

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight. Do not place overheat or air conditioning vents. Adjust levelers so that the furniture sits flat on uneven floors. Blot spills do not rub, with a clean white cloth.

Do not use harsh chemicals.

Before cleaning any part test a small spot in a hidden area.

You may need to re-tighten all bolts after initial use.



PARTS INCLUDED:



A) Multi-hook rack

[27.6 x 2.6 x 3"] x1

or

[70 x 6.5 x 7.6 cm] x3



B) Screws

[D 0.35 / 0.19 x 2.32"] x4

or

[D 8.9/4.8 x 59 mm]



C) Plastic Anchors


[D 0.35 " x 1.4" Bolt] x4

or

[D 9 x 36 mm]

STEP 1

Place the Multi-hook rack (A) on the wall in its desired location. Ensure the Multi-hook rack (A) is level and mark the location of the mounting holes in the rack on the wall. Pre-drill holes for the plastic anchors (D) at the marked hole locations using a drill and use a hammer to tap them into the wall.



STEP 2

Place the Multi-hook rack (A) back over the plastic anchors (D) and insert screws (B) as shown. Tighten with a Phillips head screw driver to complete the installation.

