

ISOBEL FLOOR LAMP

Assembly Instructions


URBAN OUTFITTERS

TOOLS REQUIRED BUT NOT INCLUDED:

Do not throw away packing materials and carton until after assembly.
Assemble all parts on a clean smooth surface

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight. Do not place over heat or Air conditioning vents.
Adjust levelers so that the furniture sits flat on uneven floors.
Blot spills do not rub, with a clean white cloth.
Do not use harsh chemicals.
Before cleaning any part test a small spot in a hidden area.
You may need to re-tighten all bolts after initial use.



PARTS INCLUDED



Shade (A)



Socket (C)



Lamp Body (D)



Lamp Base
(G)



Metal Tube
(F)



Wrench (J)

ISOBEL FLOOR LAMP

URBAN OUTFITTERS

Assembly Instructions

STEP 1: Screw the socket (C) onto the lamp body (D) until tight.

STEP 2: Pull out the metal tube (F) from the lamp base (G) and screw the threading (E) of the metal tube (F) onto the bottom of lamp body (D) until tight.

STEP 3: Attach the lamp base (G) onto the lamp body (D) with assembled metal tube (F) while aligning the lamp body (D) and the lamp base (G) to slot them together as shown.


STEP 4: Secure the metal tube (F) with lamp base (G) using metal washer and metal nut by tightening with the enclosed wrench (J).

STEP 5: Attach shade (B) to the socket (C) and secure with socket ring (A).

STEP 6: Place bulb (not included) into socket.

STEP 7: Plug into outlet, turn on switch, and enjoy your new lamp.

Use a 60W (MAX) A type incandescent bulb or 13W CFL type bulb. (Do not use bulb that exceeds recommended wattage)



EXCLUSIVE AND CONFIDENTIAL PROPERTY OF URBAN OUTFITTERS, INC.

© 2017 UO, Inc. All rights reserved, including all applicable copyright, design and patent rights.

Any unauthorized reproduction, adaptation, distribution or other infringement will be prosecuted.