

BODEN TABLE LAMP

URBAN OUTFITTERS

Assembly Instructions

NO ADDITIONAL TOOLS REQUIRED

WARNINGS:

Do not discard packing materials and the carton until assembly is complete.

Ensure all parts are present prior to assembly.

Contact customer service immediately if parts are missing.

Assemble all parts on a clean smooth surface.

Use a MAX 6W LED Type A bulb.

Do not use bulb that exceeds recommended wattage.

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.


Blot spills with a clean, white cloth; do not rub.

Do not use harsh chemicals.

Before cleaning any part, test a small spot in a hidden area.

Do not over-tighten the parts.

The parts may loosen after initial use; re-tighten as necessary.



PARTS INCLUDED:



(A) Socket Holder




(B) Washer



(C) Glass Shade



(D) Upper glass



(E) Body lamp

BODEN TABLE LAMP

Assembly Instructions

URBAN OUTFITTERS

STEP 1 As you unpack and prepare for assembly, place the contents on a carpeted or padded flat surface area.

STEP 2 Attach the Glass Shade (C) with the Washer (B) to the socket at the bottom of the Lamp Body (E). Secure the Glass Shade (C) by screwing the Socket Holder (A) onto the socket until tight. Do not overtighten.

STEP 3 Screw the Upper glass (D) onto the top thread of Lamp Body (E).

STEP 4 Insert the specified light bulb into the socket. DO NOT EXCEED THE SPECIFIED WATTAGE.

STEP 5 Plug the lamp into an outlet, turn on switch, and enjoy your lamp.

Use a MAX 6W LED Type A bulb. DO NOT USE A BULB THAT EXCEEDS THE SPECIFIED WATTAGE.

