

# BOUQUET FLOOR LAMP

URBAN OUTFITTERS


## Assembly Instructions

### WARNINGS:

Do not throw away packing materials and carton until after assembly.  
Assemble all parts on a clean smooth surface.

### CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.  
Do not place over heat or Air conditioning vents.  
Blot spills do not rub, with a clean white cloth.  
Do not use harsh chemicals.  
Before cleaning any part test a small spot in a hidden area.



## PARTS INCLUDED



(A) Socket Ring x3




(B) Shade



(C) Shade




(D) Shade




(E) Goose Neck



(F) Lower Lamp Body



(G) Upper pole



(H) Lower pole



(I) Base

# BOUQUET FLOOR LAMP

URBAN OUTFITTERS

## Assembly Instructions

---

### STEP 1

As you unpack and prepare for assembly, place the contents on a carpeted or padded flat surface area.

### STEP 2

Screw the Lower pole (H) onto the Base (I).

### STEP 3

Screw the Upper pole (G) to Lower pole (H). Insert the Goose Neck (E) into Upper pole (G) then secure by screwing in Knob (F).

### STEP 4

Screw the Shade (B) onto the sockets with Socket Rings (A) rotating in clockwise direction until tight. Repeat the same step for Shade (C) and Shade (D) as Shade (B).

### STEP 5

Screw Bulb (not included) into socket.

### STEP 6

Plug into outlet, turn on switch, and enjoy your new lamp

**Use 40W (MAX) Type A incandescent bulb or a 6W LED bulb. Do not exceed recommended wattage.**

