Willow Dining Table

Assembly Instructions

URBAN OUTFITTERS

NO ADDITIONAL TOOLS REQUIRED

WARNINGS:

Do not discard packing materials and the carton until assembly is complete.

Ensure all parts are present prior to assembly.

Contact customer service immediately if any parts are missing.

Assemble all parts on a clean, smooth surface.

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.

Blot spills with a clean, white cloth; do not rub.


Do not use harsh chemicals.

Before cleaning any part, test a small spot in a hidden area.


Do not place over heat or air conditioning vents.

Do not over-tighten the parts.

The parts may loosen after initial use; re-tighten as necessary.




PARTS INCLUDED:










(A) Table top x1



(B) Leg



(C) Leg













(G) Spring washer [1/4"] x4







(F) Bolt

[1/4" x 2-1/6"] x4





(I) Half moon washer х4



(K) Nut [5/16" x 14mm] x8


(L) Spring waher [5/16"] x8



(M) Flat waher [5/16"] x8


STEP 1

Place the table top (A) upside down and insert the legs (B & C) as shown. Insert flat washers (M), spring washers (L) and nuts (K). Tighten with supplied wrench (J).




STEP 2

Insert the stretcher bar (D) into the holes in the legs (B & C) attached to the partially assembled table. Insert the additional legs (B & C) into the partially assembled table as shown and repeat STEP 1 to attach the legs. Ensure the stretcher bar (D) is inserted into the holes in the legs (B & C) as shown. Locate the holes in the stretcher bar (D), insert half moon washers (I), flat washers (H), spring washers (G) and bolts (F). Tighten with supplied supplied hex key (E). Do not over tighten.



STEP 3

With help, flip the table upright without putting weight directly onto the legs. Turn the adjustable feet so the Table sits flat on the ground.



STEP 4

Use the rails underneath the table top as shown to support the leaf while open or, flip the leaf down.

