

MINI CHERRY LAMP

Assembly Instructions

URBAN OUTFITTERS

NO ADDITIONAL TOOLS REQUIRED

WARNINGS:

Do not discard packing materials and the carton until assembly is complete.

Ensure all parts are present prior to assembly.

Contact customer service immediately if parts are missing.

Assemble all parts on a clean smooth surface.

Use a MAX 2W LED Type T22 / C7 bulb.

Do not use bulb that exceeds recommended wattage.

CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.


Blot spills with a clean, white cloth; do not rub.

Do not use harsh chemicals.

Before cleaning any part, test a small spot in a hidden area.

Do not over-tighten the parts.

The parts may loosen after initial use; re-tighten as necessary.




PARTS INCLUDED:



(A) Socket / Chord



(B) Glass Shade



(C) Cherry Stem

MINI CHERRY LAMP

Assembly Instructions

URBAN OUTFITTERS

STEP 1

As you unpack and prepare for assembly, place the contents on a carpeted or padded flat surface area.

STEP 2

Insert the specified light bulb into the socket. DO NOT EXCEED THE SPECIFIED WATTAGE.

STEP 3

Screw the Glass Shade (B) clockwise onto the Socket / Chord (A) until tight.

STEP 4

Screw the Cherry Stem (C) clockwise onto the Glass Shade (B) until tight.

STEP 5

Plug the lamp into an outlet, and use the switch attached to the chord to turn the lamp on and off.

Use a MAX 2W LED Type T22 / C7 bulb. DO NOT USE A BULB THAT EXCEEDS THE SPECIFIED WATTAGE.

