

# TOSHI TABLE LAMP

URBAN OUTFITTERS

## Assembly Instructions

---

NO ADDITIONAL TOOLS REQUIRED

### WARNINGS:

Do not throw away packing materials and carton until after assembly.

Ensure all parts are present prior to assembly.

Contact customer service immediately if parts are missing.

Assemble all parts on a clean smooth surface.

**Use a MAX 5W LED Type C bulb.**

### CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.

Do not place over heat or air conditioning vents.


Adjust levelers so that the furniture sits flat on uneven floors.

Blot spills with a clean white cloth, do not rub.

Do not use harsh chemicals.


Before cleaning any part test a small spot in a hidden area.

You may need to re-tighten all bolts after initial use.



### PARTS INCLUDED:

---



(A) Lamp Body

# TOSHI TABLE LAMP

URBAN OUTFITTERS

## Assembly Instructions

---

### STEP 1

As you unpack and prepare for assembly, place the contents on a carpeted or padded flat surface area.

### STEP 2

Insert the specified light bulb into the socket. **DO NOT EXCEED THE SPECIFIED WATTAGE.**

### STEP 3

Clip the socket (B) into the Lamp Body (A).

### STEP 4

Plug into outlet, turn on switch, and enjoy your new lamp.

**Use a MAX 5W LED Type C bulb. Do not use bulb that exceeds recommended wattage.**

