MIKAELA 3 TIER SHEL

URBAN OUTFITTERS

Assembly Instructions

TOOLS REQUIRED BUT NOT INCLUDED:

Do not throw away packing materials and carton until after assembly. Assemble all parts on a clean smooth surface

CARE INSTRUCTIONS:


Avoid direct exposure to sunlight. Do not place overheat or air conditioning vents. Adjust levelers so that the furniture sits flat on uneven floors.

Blot spills do not rub, with a clean white cloth.


Do not use harsh chemicals.

Before cleaning any part test a small spot in a hidden area.


You may need to re-tighten all bolts after initial use.




PARTS INCLUDED








(2)x1



(3)x2







(5)X4



(a) Bolt [M6 x 10mm] x12pcs



(b) Screw [M4 x 8mm] x13pcs



(c) Feet 4pcs



(d) Screw [M4 x 40mm] x 2pcs



(e) Wall Plug 2pcs




(f) Metal Plate 2pcs




(g) Allen Key [4mm] x1pc


STEP 1




Assembly Instructions

STEP 2









Assembly Instructions

STEP 3





STEP 4

