

# Melanie Table Lamp

## Assembly Instructions

URBAN OUTFITTERS

NO ADDITIONAL TOOLS REQUIRED

### WARNINGS:

Do not discard packing materials and the carton until assembly is complete.

Ensure all parts are present prior to assembly.

Contact customer service immediately if any parts are missing.

Assemble all parts on a clean, smooth surface.

**Use E12 25W bulbs, do not exceed recommended wattage.**

**The paper shade is delicate, do not over stretch!**

### CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.


Blot spills with a clean, white cloth; do not rub.

Do not use harsh chemicals.


Before cleaning any part, test a small spot in a hidden area.

Do not over-tighten the parts.


The parts may loosen after initial use; re-tighten as necessary.



### PARTS INCLUDED:



(B) Base



(A) Paper Shade



(C) Harp



(D) Socket nut


# Melanie Table Lamp

## Assembly Instructions

URBAN OUTFITTERS


### STEP 1

Carefully insert the base (A) through the shade (B).



### STEP 2

Attach the harp (C) to the base (A) with the socket nut (D) pre-attached to the base (A). Screw the recommended bulb into the socket. Place the rings at the bottom of the shade (B) carefully into the points at the bottom of the harp (C) as shown.



### STEP 3

Carefully stretch the top of the shade (B) to the top of the harp (C). Place the rings at the top of the shade (B) into the points at the top of the harp (C) as shown. Plug in your new lamp, and use the switch attached to the chord to turn it on and off.

