

# BOW LAMP WITH GLOBE

URBAN OUTFITTERS

## Assembly Instructions

---

TOOLS REQUIRED BUT NOT INCLUDED:

### WARNINGS:

Do not throw away packing materials and carton until after assembly.

Ensure all parts are present prior to assembly.

Contact customer service immediately if parts are missing.

Assemble all parts on a clean smooth surface.

**Use a MAX 2W LED Type T22 or C7 bulb.**

### CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.

Do not place over heat or air conditioning vents.


Adjust levelers so that the furniture sits flat on uneven floors.

Blot spills with a clean white cloth, do not rub.

Do not use harsh chemicals.


Before cleaning any part test a small spot in a hidden area.

You may need to re-tighten all bolts after initial use.




PARTS INCLUDED:

---



(A) Glass Shade



(B) Lamp Body

# BOW LAMP WITH GLOBE

URBAN OUTFITTERS

## Assembly Instructions

---

### STEP 1

As you unpack and prepare for assembly, place the contents on a carpeted or padded flat surface area.

### STEP 2

Insert the specified light bulb into the socket. **DO NOT EXCEED THE SPECIFIED WATTAGE.**

### STEP 3

Attach the Glass Shade (A) onto the Lamp Body (B) secure the Glass Shade (A) by rotating in a clockwise direction until tight.

### STEP 4

Plug into outlet, turn on switch, and enjoy your new lamp.

**Use a MAX 2W LED Type T22 or C7 bulb. Do not use bulb that exceeds recommended wattage.**

