

# PARKER COFFEE TABLE

## Assembly Instructions

URBAN OUTFITTERS


### NO ADDITIONAL TOOLS REQUIRED

#### WARNINGS:


Do not throw away packing materials and carton until after assembly.  
Ensure all parts are present prior to assembly.  
Contact customer service immediately if parts are missing.  
Assemble all parts on a clean smooth surface.

#### CARE INSTRUCTIONS:

Avoid direct exposure to sunlight.  
Blot spills with a clean, white cloth; do not rub.  
Do not use harsh chemicals.  
Before cleaning any part, test a small spot in a hidden area.  
Do not place over heat or air conditioning vents.  
Do not over-tighten the parts.  
The parts may loosen after initial use; re-tighten as necessary.




### PARTS INCLUDED



(A) Top  
x1



(B) Legs  
x4



(C) Allen bolt  
[8 x 60 mm] x8



(D) Washer  
[25 mm] x8



(E) Allen key  
[6mm] x1


# PARKER COFFEE TABLE

## Assembly Instructions

URBAN OUTFITTERS

### STEP 1

Place the top (A) upside down and insert the legs (B) into the top (A) aligning the holes in each. Insert Allen bolts (C) and washers (D) then, tighten with Allen key (E).



### STEP 2

Carefully flip the table over onto its legs to complete the assembly.

