

Noah Sectional

URBAN OUTFITTERS

Assembly Instructions

TOOLS REQUIRED BUT NOT INCLUDED:


N/A

WARNINGS:


Do not throw away packing materials and carton until after assembly.
Assemble all parts on a clean smooth surface

CARE INSTRUCTIONS:


Avoid direct exposure to sunlight. Do not place overheat or air conditioning vents.
Adjust levelers so that the furniture sits flat on uneven floors.
Blot spills do not rub, with a clean white cloth.
Do not use harsh chemicals.
Before cleaning any part test a small spot in a hidden area. You may need to re-tighten all bolts after initial use.



OR



PARTS INCLUDED




A) Allen Bolt
[M8 x 60mm] 9x




A) Flat Washer
[M8x18mm] x9



C) Spring Washer
[M8 x 13mm] x9




D) Hex Key
x1




E) Legs
x9




F) Soft Pads
x9



G) Ottoman Body
x1



H) Ottoman Cushion
x1



I) Sofa Body
x1


Noah Sectional

URBAN OUTFITTERS

Assembly Instructions


STEP 1

Place the sofa body (I) and ottoman body (G) upside down onto a clean smooth surface. Unzip the pockets on the bottom of each and remove the leg and hardware package.



STEP 2

Align the legs (E) with the holes in the corners and center of the sofa body (I) and the corners of the ottoman body (G). Insert bolts (A), spring washers (C) and flat washers (B) as shown. Tighten with supplied hex key (D) as shown. Attach the soft pads to the bottom of the legs over the bolt holes. With help, flip the Ottoman and Sofa upright without leaning on the legs



Noah Sectional

Assembly Instructions

URBAN OUTFITTERS

STEP 4

Engage the clips in either orientation as shown to connect the ottoman to the sofa. Place the ottoman cushion (H) on the assembled sectional to complete assembly.

