




S.Det är lämpligt att denna information överlämnas till användaren av anläggningen.
GB. It is appropriate that this information is passed on to the user of the installation.
D. Diese Informationen sind für den Benutzer der Anlage vorgesehen.
SF. Tämä ohje on suositeltava luovuttaa.

Montageanvisning Halo 450/600 Lina

Assembly instruction Halo 450/600 Wire



3 Skarvdosa (325-8035) fästas på wire.



S.Om armaturens kabel skulle skadas eller om armaturen inte fungerar som den ska, skall dessa komponenter kontrolleras/bytas av tillverkaren eller av tillverkaren utsedd person.

GB.If the luminaire cable is damaged or if the luminaire is not working properly. It shall exclusively be checked/replaced by the manufacturer or by the manufacturer designated person.



(S)


(GB)

Armaturen bör placeras så att långvarigt tittande direkt in i armaturen inte förväntas på ett avstånd närmare än 1m

The luminaire should be positioned so that prolonged staring into the luminaire at a distance closer than 1m is not expected



"The light source shall only be replaced by the manufacturer or his designated person."
 Ljuskällan ska enbart bytas ut av tillverkaren eller hans utsedda person



Blå/ Blue = Nolla/ Neutral
 Brun/ Brown = Fas/ Live
 Gulgrön/ Green yellow = Jord/ PE
 Svart/ Black = Prog/Dali
 Grå/ Grey = Prog/Dali

ateljé Lyktan

SE-296 81 Åhus, Sweden
 Tel: +46 44 28 98 00
 Fax: +46 28 98 38
 info@atelje-lyktan.se
 www.atelje-lyktan.se

MA8480

2016-02-24
 HHT