

Fuse table

PILO ON/OFF 1500lm

Maximum loading of automatic of circuit breakers

Driver: LC 17W 250–700MA FLEXC C EXC	C10	C13	C16	C20		B10	B13	B16	B20
Number of drivers	41	55	66	83		25	33	40	50

* Input voltage 230V, Time measured at 50% Ipeak

PILO ON/OFF 2150lm

Maximum loading of automatic of circuit breakers

Driver: LC 25W 350–1050MA FLEXC C EXC	C10	C13	C16	C20		B10	B13	B16	B20
Number of drivers	41	53	65	81		25	32	39	49

* Input voltage 230V, Time measured at 50% Ipeak

Fuse table

PILO ON/OFF 2750-3600lm

Maximum loading of automatic of circuit breakers

Driver: LC 17W 250–700MA FLEXC C EXC	C10	C13	C16	C20		B10	B13	B16	B20
Number of drivers	18	23	28	35		11	14	17	21

* Input voltage 230V, Time measured at 50% Ipeak

PILO DALI 1500lm

Maximum loading of automatic of circuit breakers

Driver: LC 25W 350–1050MA FLEXC C EXC	C10	C13	C16	C20		B10	B13	B16	B20
Number of drivers	35	46	58	73		21	28	35	44

* Input voltage 230V, Time measured at 50% Ipeak

Fuse table

PILO DALI 2150lm

Maximum loading of automatic of circuit breakers

Driver: LC 17W 250–700MA FLEXC C EXC	C10	C13	C16	C20		B10	B13	B16	B20
Number of drivers	30	41	53	66		18	25	32	40

* Input voltage 230V, Time measured at 50% Ipeak

PILO DALI 2750-3600lm

Maximum loading of automatic of circuit breakers

Driver: LC 25W 350–1050MA FLEXC C EXC	C10	C13	C16	C20		B10	B13	B16	B20
Number of drivers	21	30	36	46		13	18	22	28

* Input voltage 230V, Time measured at 50% Ipeak