

## **ENGINEERING BULLETIN**

## Subject: INSTINCT Solo DHW Setpoint Setting

Date: 11/13/19

Introduction of the INSTINCT Combi required changes to the CTRLMax Installer DHW menu. The settings in the Installer DHW menu will change depending on the INSTINCT model. Indirect Water Heater settings are shown for the INSTINCT Solo and Instantaneous Water Heater settings are shown for the INSTINCT Combi.

Initial shipments of INSTINCT Solo units display the DHW Setpoint setting in the Installer DHW menu but do not allow it to be adjusted. The DHW Setpoint setting can still be adjusted in the EZ Setup menu.

All INSTINCT Solo units shipped after 11/1/19 contain display software version 0.29 which allows DHW Setpoint to be adjusted in both EZ Setup and the Installer DHW menu.

Please contact technical support at <u>techsupport@triangletube.com</u> or (856) 228-8881 x575 with any questions regarding this issue.

140°F 68°F 168°F 68°F 168°F	DHW Se	etpoint			
				-~	
	68°F	168°F	~ <	0	>
	â	Ç		-~	

DHW Setpoint Adjustment

Triangle Tube - 1240 Forest Parkway, Suite 100 - West Deptford, NJ 08066 Tel: (856) 228-8881 - Fax: (856) 228-3584 - e-mail: info@triangletube.com