




Boiler access from just about anywhere.


This app works with the iAssist Module 1.0 to offer an easy and efficient way to access your boiler right from any device or computer. iAssist Module 1.0 comes standard on Exalt Floor Standing boilers and is compatible for Exalt Wall and Gallant.



Available for download on IOS or Android



to all your customer's boilers remotely



PART #	DESCRIPTION	EXALT FLOOR	EXALT WALL	GALLANT WALL
EXRKIT119	Wi-Fi Module 1.0 Wall Bracket	X		
EXRKIT122	Wi-Fi Module 1.0 Kit		X	X
EXRKIT123	Wi-Fi Module 1.0	X	X	X