Transformer Replacement Kit for PRESTIGE

Triangle Tube

Kit Part Number: PSRKIT19

Parts List

1. Transformer
2. 2 -Self-tapping Screws

Recommended tools:

- Phillips Screw Driver.

Prestige Transformer

WARNING

Indicates a potentially hazardous situation which, if ignored, can result in serious injury or substantial property damage.

NOTICE

Indicates special instructions on installation, operation or maintenance, which are important to equipment but not related to personal injury hazards.

WARNING

For your safety, turn off electrical power supply at service panel before proceeding to avoid possible electrical shock hazard. Failure to do so can cause severe personal injury or death.

WARNING

Failure to follow instructions below can result in severe personal injury or damage if ignored.

- Instructions are for a qualified installer/ service technician.
- Read all instructions before proceeding.
- Follow instructions in proper order.

Transformer Replacement Kit
for PRESTIGE

Instructions

1. Turn power to the unit "OFF".

2. Remove the front jacket panel.

NOTICE

> **Before proceeding to the following steps mark and label all connections and the location of the connections prior to disconnecting any wire connections.**

3. Disconnect the Transformer cable connector from the MCBA Control Module.

4. Remove the Transformer mounting screws. Do not discard the Transformer, if the Transformer is being replaced under warranty.

NOTICE

> **Contact Triangle Tube Customer Service to determine warranty status and for a RGA number to return the damage Transformer under warranty.**

5. Mount the new Transformer onto the control panel using the screws included with the kit. Ensure all screws are tight and the Transformer is securely mounted.

6. Reconnect the Transformer cable to the MCBA Control Module.

7. Remount the front jacket panel to the boiler.

8. Turn power to the unit "ON" and return the boiler to service.

9. To verify operation of the boiler, reference the star-up procedures as listed in the installation manual.

Fig. 1: Transformer Mounting