

THUMA

Let's get together.

Essential Dresser


www.thuma.co

Assemble with two people for a safe, efficient setup.


Take care during assembly. Do not dispose of any packaging or contents of the shipping carton until assembly is complete. Avoid balancing unsupported pieces and do not bend over near unsecured pieces. Keep children out of the way during assembly.

Configurations

These assembly instructions work for both configurations.



5-Drawer Dresser




6-Drawer Dresser

Levelers


Move the dresser to its desired location.

If the floor is level, skip this step. If not, adjust the levelers at each corner.

- A. Carefully flip the dresser toward the back at a 90° angle.
- B. Rotate the levelers at each corner to level the dresser with the floor, then flip it back to the horizontal position. Adjust each leveler as needed to ensure the dresser sits evenly and securely.



Repeat this step as needed.



Anti-Tipping Hardware

To prevent risk of serious injury due to furniture tipping over, secure the dresser to the wall using anti-tipping hardware included.

Cable



Wall Screw



Wall Anchor




Short Screw



Step 1


Move the dresser to desired location.

Mark the wall to indicate the center of the dresser's top edge.




Step 2

Rotate the dresser so it sits at a 90° angle from the wall.



Step 3

Mark the wall 3 ¼ inch below the Step 1 mark.
This is where the Anti-Tipping Hardware should be placed.




Step 4

A. Drill a hole in the wall with a 9/32" drill bit at the marked location in Step 3.


B. Hammer the **wall anchor** into the hole.

C-D. Secure one end of the **cab**le to the wall with the **wall screw**.



Step 5



Rotate the dresser toward the wall, but leave a bit of space in between for the final steps.



Step 6


Use the short screw to attach the cable to the dresser.

Tighten by hand.



Step 7


Push the dresser against the wall.



Drawer Opening

Top drawer(s) open by pulling.

All other drawers are push-to-open.



Enjoy.

Light a candle, play some jams, pour a refreshment.
Share moments of oasis @thuma.co


For help and more to love, scan the QR code below.




Additional Information

Remove and Reattach Drawers


Remove Top Drawer(s)




Remove one drawer at a time. Fully open the drawer.



Locate the locking devices underneath the drawer at the front left and right corners. Press both release levers at the same time.




While holding the release levers, pull the drawer slightly outward and lift the front of the drawer to disengage it from the slides.




Continue pulling the drawer outward until the rear disengages. Lift and pull the drawer out.

Repeat this step for other drawers as needed.


Remove Bottom Drawers




Remove one drawer at a time, from top to bottom. Fully open the drawer.



Locate the plastic tabs underneath the drawer on each slide. Pull both tabs out from the slides to unlock.




Lift the front of the drawer slightly to disengage it from the slides.




Pull the drawer outward until the rear disengages. Lift and pull the drawer out.

Repeat this step for other drawers as needed.


Reattach Bottom Drawers




Install one drawer at a time, starting with the bottom-most drawer. Pull the first two slides fully out. Keep the plastic tabs pulled out in the unlocked position.



Position the drawer level and centered between the slides. Gently set the back of the drawer onto the slides, aligning the hooks at the back of the slides with the opening at the back of the drawer.




Gently lower the front of the drawer onto the metal pin at the front of the slides. Make sure the drawer fits evenly into the slides.




Press both plastic tabs into the slides to lock the drawer in place. The drawer should not lift away from either side.

Repeat this step for other drawers as needed.


Reattach Top Drawer(s)




Install one drawer at a time. Pull the first two slides fully out.



Position the drawer level and centered between the slides. Gently set the back of the drawer onto the slides.



Push the drawer straight into the dresser until fully closed. A “click” confirms that the locking devices have engaged with the slides.



Gently open the drawer. Pull each slide forward from underneath the drawer to confirm both sides are locked in place. The drawer should not lift away from either side.

Repeat this step for other drawers as needed.

