

MOVE TO ELECTRIC



Up to 519 km



77 kWh



AC 11 kW: 7h 30 min (0-100%)



DC 135 kW: 34 min (0-80%)

Getting started

- If your car is charging, you must first displug out the charging cable that is connected behind the right back door. ...
- You first need to unlock the car then you have 60 seconds to disconnect the charging cable.
- If it does not come loose, unlock the car again with the key and try again.
- If you have any problems to disconnect the charging cable, please contact us and we will help you.
- If the car is not charging, just open the car and get in it.

Start



- The car is "Key-Less", which means it is enough that you have the key in your pocket when you get in the car. In this car you do not need to use any start button to start the car.
- Start the car by holding down the brake pedal, press the start button in the car until "ping" is heard and "Ready" in green lights up in the display behind the steering wheel.



Driving



- When breaking with the brake pedal, braking take place by recovering the kinetic energy. Thus, the battery charges through so –called recuperation. As a driver you do not have to do anything, everything happens automatically, and you can look at the power goals in the green field in the display behind the steering wheel.
- When only 10 km remain, a symbol in the shape of a turtle lights up. In the first instance, comfort functions such as the climate control are switched off, acceleration may also be slower.

Charge

- In the trunk of your car, you find the charging cable for your car.
- The charging door is located behind the right back door.

Typ 2 (mode 3) kabel. Used for charging in a charging box.



- You can charge your car in charging boxes that have Type 2 connector.
- The charging boxes can sometimes be equipped with a fixed charging cable, if there not one, use the charging cable in the trunk of your car.

CCS = Fast charging



- To charge with a fast charger (CCS), you also need to remove the cover in the charging door for the charger to fit.

Start charging

- Select cable and connect first to the pole/socket, then to the car.
- Check that the green light on the car's charging socket turns on.
- Lock the car, the charger is locked and can not be removed if the car is locked.