



1800-102-8888



TEXINO
Industries
Est. 1956



How to install a Pressure Booster Pump


[Pressure Booster Pumps Mainpage](#)

[Pressure Booster Pump FAQ's](#)


[Pressure Booster Pump Buyer Guide](#)

[Pump Selector](#)


1. Verify the pressure rating of the overall plumbing system where the pumpset is to be installed, ensuring the pipes can withstand the maximum operating pressure of pump.
2. Thoroughly inspect pipelines for leaks before installation to prevent potential issues and ensure seamless operation
3. Refer Fig. 1, shown below to ensure all accessories are fitted properly.



4. Prepare a level concrete foundation for mounting the pressure booster pump and tighten the motor base using the foundation bolts as shown in Fig. 2 below:



5. Use prescribed pipe sizes as mentioned on the product name plate.
6. Ensure that pipe joints are properly fitted.
7. Ensure pressure tank and pressure controller settings are done right and align with field requirement.
8. Refer Fig. 3, shown below for negative suction installation and ensure pump is filled with water for priming.



9. Refer Fig. 4, shown below for positive suction installation.