

eu Totech ASSEMBLY INSTRUCTION

Remove all items from the carton. Verify all pieces before assembly

PART LIST


KEY	QTY	DESCRIPTION	KEY	QTY	DESCRIPTION	KEY QTY	DESCRIPTION
1	5	Caster	7	1	Backrest	11 5	Back Attachment Screws
2	1	Base	0	4	Mechanism Screws	11 3	(1/4"*2")and Washers
3	1	Seat Post	0		(M8*20MM)	NOTICE:USE SCREWS WITH RED	
4	1	Seat Post Cover	9	2	Armrest	LOCTITE	TO ATTACH BACKREST.
5	1	Mechanism	10	8	Armrest Screws (1/4"*1-3/4")	12 1	Allen Wrench (4mm)
6	1	Seat				13 1	Allen Wrench (5mm)







NOTICE: EVERY 6 MONTHS, PLEASE MAKE SURE ALL BOLTS, SCREWS AND KNOBS ARE FULLY TIGHTENED TO ENSURE STABILITY.



MECHANISM OPERATION INSTRUCTION WHILE SEATED:

- (A) SEAT HEIGHT ADJUSTMENT: Pull lever up.Release lever when desired position is reached
- (B) BACK TILT ADJUSTMENT: Pull lever out horizontally. Move backrest to tilt. To lock in upright position, push lever in.
- (C) TILT TENSION ADJUSTMENT KNOB: Rotate knob clockwise/counterclockwise to adjust tilt tension based on body weight.

PREVENTIVE MAINTENANCE AND WARNING!

- USE THIS PRODUCT ONLY FOR SEATING ONE PERSON AT A TIME.
- DO NOT USE THIS CHAIR AS A STEP STOOL/LADDER.
- DO NOT SIT ON ANY PART OF THE CHAIR EXCEPT THE SEAT.
- DO NOT USE CHAIR ON UNEVEN FLOOR SURFACES.
- DO NOT USE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE TIGHT.AT LEAST EVERY SIX MONTHS, CHECK ALL BOLTS, SCREWS AND KNOBS TO BE SURE THEY ARE TIGHT.
- IF ANY PARTS ARE MISSING, BROKEN, DAMAGED OR WORN, STOP USE OF THE PRODUCT UNTIL REPAIRS ARE MADE USING FACTORY AUTHORIZED PARTS.
- · DISPOSE OF PACKAGING PROPERLY, PLASTIC BAG IS NOT A TOY. DO NOT USE PLASTIC BAG AS HEAD COVERING-IT MAY CAUSE SUFFOCATION.
- · FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.