



Software Release Note

Aural ID 2.1.0

Software Release Note

Aural ID 2.1.0 for Mac Computers

Aural ID 2 offer the ultimate in tailor-made headphone monitoring. Create your personal HRTF profile, download the Aural ID 2 app, and enjoy a headphone listening experience you can finally trust.

This update is highly recommended for all Aural ID users.

NOTE: Installation of this version will remove any Aural ID files previously created with earlier versions. You are required to reconfigure I/O settings, choose the appropriate monitoring layout, and download your profile again after installation.

Apple Silicon is preferred. Performance issues may occur with loaded Intel CPUs. It's recommended to turn off head tracking and closing applications using CPU if performance issues occur.

Computer requirements

	Windows 10, 11 (64-bit)	macOS 11-26 Apple Silicon CPU	macOS 11-15 Intel CPU
Aural ID App 2.0	Not available	Compatible	Compatible
Aural ID Head Tracker	Not available	Compatible	Compatible
Hard Disk Space	2 GB minimum		

* Link to the software download is <https://my.genelec.com/>

Internet Connection	<p>An internet connection is required</p> <ul style="list-style-type: none">• Register / Login to My Genelec account• during downloading Aural ID 2 installation package*• occasionally to update your license to use Aural ID 2• occasionally to download your personal Aural ID HRTF data complementary head-and-torso simulator HRTF data <p>The Genelec Aural ID Creator Mobile App is required</p> <ul style="list-style-type: none">• to open your personal My Genelec account• to place an order for your personal Aural ID profile (HRTF) <p>Personal Aural ID profile file contains your personal HRTF and is needed for the most accurate rendering of the virtual loudspeakers in the Aural ID application.</p> <p>The Aural ID Creator App is available in the app stores for Android and iPhone.</p>
----------------------------	---

Changes in Aural ID 2.1.0 application

The feature set of the Aural ID 2 application includes all the features in original Aural ID plugin and introduces several improvements and additions.

- Aural ID folder structure improvements; Aural ID profiles are stored in Profiles -folder and Aural ID settings are stored in Setups -folder.
- Output EQ and Envelopment controls are moved from the application menu to the main UI.
- Added Cancel and Confirm -buttons to the settings pages. Settings will be saved to a setup file when confirming the changes.
- Added a bypass functionality to the LF Envelopment settings page.
- Improved the Head Tracker settings page.
- Added a bypass functionality to the Aural ID Output EQ settings page.
- Improved a Virtual Channel settings page.
- Setting pages are modal.
- Improved a HRTF profile loading.
- Added an audio buffering status label to the bottom left corner of the main page.
- Improved audio processing.
- Changed a cell size of the grid.
- Maximum audio buffer size is 1024 samples.
- Output level meter scaling changed.
- Added input level indicators to the virtual monitor icons.
- Channel naming convention updated.
- Audio Bridge menu renamed to I/O Setup.

More information

To download Aural ID 2 application install package visit you MyGenelec account. Aural ID 2 Operating Manual gives full coverage of all details.

If you have any questions, please do not hesitate to contact us at support@genelec.com.

Genelec Oy

International enquiries

Genelec Oy
Olvitie 5
FI 74100 Iisalmi
Finland
Phone +358 17 83881
Fax +358 17 812 267
Email genelec@genelec.com

In Sweden

Genelec Sverige
Tureholmsvägen 12
125 35 Älvsjö
Sweden
Phone +46 8 449 5220
Email sweden@genelec.com

In the USA

Genelec, Inc.
7 Tech Circle
Natick MA 01760
USA
Phone +1 508 652 0900
Fax +1 508 652 0909
Email genelec.usa@genelec.com

In China

Beijing Genelec Audio Co.Ltd
Room 101, Building B33
Universal Business Park
No. 10 Jiuxianquiao Road
Chaoyang District
Beijing 100015
China
Phone +86 10 5823 2014
Phone +86 400 700 1978
Email genelec.china@genelec.com

In Japan

Genelec Japan Inc
2-22-21 Akasaka
Minato-ku
JP-107-0052 Tokyo
Japan
Phone +81 3 6441 0591
Email genelec.japan@genelec.com