

KitchenAid

BREAD BOWL WITH BAKING LID

5KSM2CB5B

OWNER'S MANUAL

EN	Owner's Manual	2
DE	Bedienungsanleitung	7
FR	Le manuel d'utilisation	13
IT	Manuale del proprietario	19
NL	Gebruikershandleiding	24
ES	El manual del propietario	29
PT	Manual do proprietário	33
EL	Εγχειρίδιο Κατοχού	38
SV	Användarhandbok	43
NO	Brukerhåndbok	47
FI	Omistajan Opas	51
DA	Brugervejledning	55
IS	Notandahandbók	59
PL	Instrukcja Obsługi	63
CS	Uživatelská Příručka	68
TR	Kullanıcı Kilavuzu	72
UA	Посібник з експлуатації	76
AR	دليل المالك	1

PRODUCT SAFETY

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed. Please refer to the basic Important Safeguards as outlined in the owner's manual included with your Stand Mixer.

SAVE THESE INSTRUCTIONS

For complete details on product information, instructions and videos, including Guarantee information, visit www.KitchenAid.co.uk or www.KitchenAid.eu. This may save you the cost of a service call. To receive a free printed copy of the information online, call **00 800 381 040 26**.

PRODUCT ASSEMBLY

ATTACHING THE BREAD BOWL

Before First Use

Your Stand Mixer is individually adjusted at the factory for optimal performance. When using the Bread Bowl with Baking Lid, it may be necessary to readjust the beater-to-bowl clearance. Please refer to the Stand Mixer owner's manual for complete information on adjusting the beater-to-bowl clearance.

IMPORTANT: Before use, wash with hot, soapy water; rinse and dry thoroughly. It is not necessary to season the Bread Bowl with Baking Lid before use.

NOTE: This Bread Bowl is designed to fit all 4.3 L to 4.8 L Tilt-Head Stand Mixer models except model KN15E1X. The Bread Bowl with Baking Lid is oven-safe (up to 260°C/500°F). Follow these instructions to attach the Bread Bowl to your Stand Mixer.

1. Turn the Stand Mixer off (0) and unplug.
2. Unlock and lift the Motor Head. Then, lock* the head to keep it lifted.
3. Place the Bread Bowl on the clamping plate to secure in place.
4. Attach the Dough Hook for your recipe, using the directions in the Stand Mixer owner's manual. Then place the Motor Head back in the down position and lock* into place.

PRODUCT USAGE

NOTE: Product usage steps based on insert recipe card. Recipe steps may vary based on different recipes in other recipe books. The Bread Bowl with Baking Lid is oven-safe (up to 260°C/500°F).

MIX AND KNEAD

1. Once bowl and dough hook attachment are secured on Stand Mixer, you will add in ingredients into the Bread Bowl.

NOTE: See ingredient list on recipe insert.

*Locking option is available on select models.

PRODUCT USAGE (CONTINUED)

2. Turn the mixer to speed 2 to combine dry ingredients. After about 30 seconds, slowly stream in warm water. Allow the mixer to knead the ingredients for 1½ - 2½ minutes - or, until the dough pulls away from the bowl and forms a ball.
3. Turn the Stand Mixer off (0) and unplug. Remove dough from the Bread Bowl.
4. **Raise the Motor Head:** Unlock and lift the Motor Head. Then, lock* the head to keep it lifted.
5. **Remove the accessory:** Press the accessory upward, turn it and pull it away from the beater shaft.
6. **Remove the Bread Bowl:** Twist to unlock the Bread Bowl from the clamping plate.

PROOF

1. If necessary, hand knead the dough on the counter so it forms a smooth round ball. Return to Bread Bowl.
2. Place the dough in the Bread Bowl and dust the top of the dough with a bit of flour. Use a hand to turn and coat the dough in flour, then cover the bowl with the Baking Lid. Let the dough rise for 60 minutes. Use measurements marks** on side of Bread Bowl for visual rising level.
3. Uncover the bowl and gently pull the dough from the bowl onto a generously floured surface.
4. With dough in a rough round in front of you, pinch the top of the dough, stretch it away from you, then fold it into the centre of the dough like you are folding an envelope. Give the dough a slight twist and do the same thing to the portion now at the top. Continue turning, stretching and folding the dough into the centre for three to four full circles. (You will notice it gets harder to stretch the dough as you work.)
5. After the final stretch and fold, flip the dough over, fold side down. Gently place both hands on each side of the round and gently curl your right palm around the right edge while using your left hand to rotate the round on the surface. This action will smooth the dough into a round mound.

RISE

1. Generously flour the inside of the Bread Bowl and the top of the dough. Return the dough, seam side down, to the Bread Bowl. Cover the bowl with the Baking Lid and allow it to rise for 30 more minutes.
2. Once dough has risen, remove the lid from the Bread Bowl and line the inside of the lid with a round of parchment paper, or coat with grease and flour. Remove dough from the Bread Bowl and carefully invert the round from the Bread Bowl onto the Baking Lid (so the fold side is now facing up) being careful not to deflate it or disturb the shape.

TIP: To avoid bread sticking to lid, use parchment paper or coat the lid with grease and flour prior to baking.

SHAPE AND SCORE ON LID

1. Shape and score the dough, using sharp knife or scoring tool.
Optional: Sprinkle flour on top of dough, egg wash, or herbs for customization.
2. Gently place the Bread Bowl upside down on top of the dough and Baking Lid to secure in place.

*Locking option is available on select models.

**Marks are for visual reference only and will depend on recipe size used.

PRODUCT USAGE (CONTINUED)

BAKE

1. Preheat oven to 232°C/450°F. Place the Bread Bowl with Baking Lid side down on middle oven rack and bake it for 30 minutes.

NOTE: Set your rack as close to the centre of the oven as possible while still leaving enough height for the Bread Bowl with Baking Lid to fit.

TIP: When inserting into oven, place lid side down on to rack.

2. Remove the Bowl covering to expose the bread and finish baking for 10 more minutes, this will help brown the crust. Remove to a cooling rack and let cool completely before slicing

IMPORTANT: Always use oven mitts when removing Bread Bowl or racks.

CARE AND CLEANING

IMPORTANT: Allow the appliance to cool completely before putting on or taking off parts, and before cleaning the appliance.

1. The Bread Bowl and Lid may be washed in an automatic dishwasher on the top or bottom rack or, clean thoroughly in hot sudsy water and rinse completely before drying.
2. The Bread Bowl should be placed upside down if washing in an automatic dishwasher.

BREAD BOWL WITH BAKING LID CARE

1. To remove baked-on food, soak the Bread Bowl in hot, soapy water for 15-20 minutes or as needed before placing it in the dishwasher.
2. Always dry the Bread Bowl thoroughly before storing.
3. After using the Bread Bowl with the Stand Mixer, some marks may appear where the Bread Bowl locks in to the base of the Stand Mixer. The marks are normal and can be removed by cleaning with an abrasive cleaner and sponge.
4. You may also clean using an abrasive sponge and a baking soda and warm water mixture, vigorously scrub stains to reduce staining appearance.
5. It is recommended to minimize sudden changes in the temperature of your ceramic. Ceramic must be heated or cooled gradually to avoid thermal shock and possible damage.
6. When the Bread Bowl with Baking Lid is hot, do not place it in contact with anything cold, such as cold water or a cold surface. When you take it out of the oven, place it on a neutral surface and let fully cool.

TERMS OF KITCHENAID GUARANTEE ("GUARANTEE")

Covering U.K. - Ireland - South Africa - UAE

KitchenAid Europa, Inc., Nijverheidslaan 3, Box 5, 1853 Strombeek-Bever, Belgium ("Guarantor") grants the end-customer, who is a consumer, a Guarantee pursuant to the following terms.

FOR U.K.:

The Guarantee applies in addition to and does not limit or affect the statutory warranty rights of the end-customer against the seller of the product. In summary, the Consumer Rights Act 2015 says products must be as described, fit for purpose and of satisfactory quality. During the expected lifespan of your product your legal rights entitle you to the following:

- Up to 30 days: if your product is faulty, then you can get an immediate refund.
- Up to six months: if your product can't be repaired or replaced, then you're entitled to a full refund, in most cases.
- Up to six years: if your product does not last a reasonable length of time you may be entitled to some money back.

These rights are subject to certain exceptions. For detailed information please visit the Citizens Advice website www.adviceguide.org.uk or call **03454 04 05 06**.

TERMS OF KITCHENAID GUARANTEE ("GUARANTEE") (CONTINUED)

FOR IRELAND:

The Guarantee applies in addition to and does not limit or affect the statutory warranty rights of the end-customer against the seller of the product under the European Communities (Certain Aspects of the Sale of Consumer Goods and Associated Guarantees Regulations 2003 (S.I. No. 11/2003)) and other enactments governing the sale of consumer goods.

FOR SOUTH AFRICA:

The Guarantee applies in addition to and does not limit or affect the statutory warranty rights of the end-customer against the seller of the product. In summary, the Consumer Protection Act, 2008 says that products must be: (i) reasonably suitable for the purpose for which they are intended; (ii) in good working order, of good quality and free of any defects; (iii) useable and durable for a reasonable period of time, having regard to the use to which they would normally be put and to all the surrounding circumstances; and (iv) in compliance with any applicable standards or any other public regulations.

During the expected lifespan of your product and where the products are not purchased online, your legal rights will entitle you to the following:

- You will be entitled to a full refund, if you did not have the opportunity to examine the product before delivery and if you rejected delivery of the product on the basis that the type and quality of the product was not as reasonably expected or did not reasonably conform to the material specifications.
- Within 5 business days after delivery: you may rescind your purchase and request a refund, if your purchase resulted from direct marketing.
- Within 10 business days after delivery: you will be entitled to a full refund, if it is found that the product was unsuitable for a particular purpose specifically communicated to you by the Guarantor.
- Within 15 business days after delivery: you will be entitled to a refund if: (i) the product was not delivered to you; or (ii) if you returned the product to the Guarantor.
- Within 6 months after delivery: you will be entitled to a refund or a replacement product, if the product is defective or fails to operate in terms of its specifications.

Where you have purchased a product online your legal rights will be governed by the Electronic Communications and Transactions Act, 2002 and you will be entitled to the following:

- Within 7 days after conclusion of the transaction or after delivery: you may cancel your purchase without reason and without penalty.
- Within 30 days of the date of cancellation of the transaction: you will be entitled to receive a refund, if you have already made payment.
- You will only be liable for the direct costs of returning the product to the Guarantor.

FOR UAE:

The Guarantee applies in addition to and does not limit or affect the statutory warranty rights of the end-customer against the seller of the product.

1. SCOPE AND TERMS OF THE GUARANTEE

- a) The Guarantor grants the Guarantee for the products mentioned under Section 1.b) which a consumer has purchased from a seller or a company of the KitchenAid-Group within the following countries: U.K., Ireland, or South Africa, or the United Arab Emirates (UAE).
- b) The Guarantee period depends on the purchased product and is as follows:

Five Year full guarantee from date of purchase.

- c) The Guarantee period commences on the date of purchase, i.e. the date on which a consumer purchased the product from a dealer or a company of the KitchenAid-Group.
- d) The Guarantee covers the defect-free nature of the product.
- e) The Guarantor shall provide the consumer with the following services under this Guarantee, at the choice of the Guarantor, if a defect occurs during the Guarantee period:
 - Repair of the defective product or product part, or
 - Replacement of the defective product or product part. If a product is no longer available, the Guarantor is entitled to exchange the product for a product of equal or higher value.
- f) If the consumer wishes to make a claim under the Guarantee, the consumer has to contact the country specific KitchenAid service centres or the Guarantor directly at KitchenAid Europa, Inc. Nijverheidslaan 3, Box 5, 1853 Strombeek-Bever, Belgium;

Email-Address U.K.: CONSUMERCARE.UK@kitchenaid.eu

Email-Address IRELAND: CONSUMERCARE.IE@kitchenaid.eu

Toll Free Number U.K. & IRELAND: 00 800 381 040 26

TERMS OF KITCHENAID GUARANTEE ("GUARANTEE") (CONTINUED)

FOR SOUTH-AFRICA:

Our local KitchenAid Distributor:

KitchenAid Africa
PO Box 52102
V&A Waterfront
Cape Town
8002

Contact our distributor:

Telephone: +27 21 555 0700

You can contact our Customer Service Centre for Small Domestic Appliances from 8.30 am to 1.00 pm and from 1.30 pm to 5.00 pm or write to us at the following address: hello@kitchenaidafrica.com

FOR UAE:

AL GHANDI ELECTRONICS.

POST BOX NO. 9098,
DUBAI, UNITED ARAB EMIRATES
Toll free number: +971 4 2570007

- g) The costs of repair, including spare parts, and any postage costs (if applicable) for the delivery of a defect-free product or product part shall be borne by the Guarantor. The Guarantor shall also bear the postage costs for returning the defective product or product part if the Guarantor or the country specific KitchenAid customer service centre requested the return of the defective product or product part. However, the consumer shall bear the costs of appropriate packaging for the return of the defective product or product part.
- h) To be able to make a claim under the Guarantee, the consumer must present the receipt or invoice of the purchase of the product.

2. LIMITATIONS OF THE GUARANTEE

- a) The Guarantee applies only to products used for private purposes and not for professional or commercial purposes.
- b) The Guarantee does not apply in the case of normal wear and tear, improper or abusive use, failure to follow the instructions for use, use of the product at the wrong electrical voltage, installation and operation in violation of the applicable electrical regulations, and use of force (e.g. blows).
- c) The Guarantee does not apply if the product has been modified or converted, e.g. conversions from 120 V products to 220-240 V products.
- d) The provision of Guarantee services does not extend the Guarantee period, nor does it initiate the commencement of a new Guarantee period. The Guarantee period for installed spare parts ends with the Guarantee period for the entire product.
- e) **FOR SOUTH-AFRICA & UAE ONLY:**
Further or other claims, in particular claims for damages, are excluded unless liability is mandatory by law.


After expiry of the Guarantee period or for products for which the Guarantee does not apply, the KitchenAid customer service centres are still available to the end-customer for questions and information.

Further information is also available on our website:

- For U.K. & Ireland www.kitchenaid.eu
- For South-Africa: www.kitchenaidafrica.com
- For UAE: www.KitchenAid-MEA.com

PRODUCT REGISTRATION

Register your new KitchenAid appliance now: <http://www.kitchenaid.eu/register>



KitchenAid

©2022 All rights reserved.

KITCHENAID and the design of the stand mixer are trademarks in the U.S. and elsewhere.