# INSTALLATION **& OPERATION** MANUAL

Rocker Max Pa 440-L6

Code 3,® Inc., a subsidiary of Public Safety Equipment, Inc.



### Introduction

The Rocker Max Pak<sup>™</sup> 440-L6 Switchbox is a 6 switch control center, with the addition of 3 level lighting control. Each indvidual output is rated for 15A maximum and is protected with a 20A ATO fuse. L1 thru L3 is protected by a 40A circuit breaker. (Each group is rated for 40A maximum.)

Total box switching capacity is 60 AMPS. Be careful not to exceed any of these maximum ratings.


### **WiringProcedure**

NOTE: Make sure the fuses are removed and the positive battery terminal has been disconnected before installing or servicing this unit.

- 1) The installer needs to determine the current load in amps, of each of the devices to be switched by the Rocker Max Pak™.
- 2) Connect the device(s) to the desired switch(s), noting the current limitations of each switch and group of switches. (See FIG. 1)
- The 8ga. red wire should be run from the switchbox to the (+) side of the battery, the alternator, or the stud on the battery side of the solenoid.
- The red wire "B" powers the backlighting. Connect it to a +12 volt ignition switched circuit or the parking lights circuit, as desired. Backlighting is provided by an array of solid state LED's. A user supplied 1 amp fuse is highly recommended for this input.
- Connect the black "G" wire to the vehicle chassis ground.
- Turn all switches OFF, install all fuses and attach the battery positive terminal. Check all power fuses to assure against short circuits. If any have opened, check associated wiring for cuts, defects or improper connections.
- One at a time, turn each device on. Again check for proper operation.
- 8) If a fuse needs replacement, 20 amp ATO style fuses must be used.

NOTE: Larger wires and tight connections will provide longer service life for components. For high current wires it is highly recommended that terminal blocks or soldered connections be used with shrink tubing to protect the connections. Do not use insulation displacement connectors (e.g. 3M® Scotchlock type connectors). Route wiring using grommets and sealant when passing through compartment walls. Minimize the number of splices to reduce voltage drop. High ambient temperatures (e.g. underhood) will significantly reduce the current carrying capacity of wires, fuses, and circuit breakers. Use "SXL" type wire in engine compartment. All wiring should conform to the minimum wire size and other recommendations of the manufacturer and be protected from moving parts and hot surfaces. Looms, grommets, cable ties, and similar installation hardware should be used to anchor and protect all wiring. Fuses or circuit breakers should be located as close to the power takeoff points as possible and properly sized to protect the wiring and devices. Particular attention should be paid to the location and method of making electrical connections and splices to protect these points from corrosion and loss of conductivity. Ground terminations should only be made to substantial chassis components, preferably directly to the vehicle battery. The user should install a fuse sized to approximately 125% of the maximum Amp capacity in the supply line to protect against short circuits. For example, a 30 Amp fuse should carry a maximum of 24 Amps. DO NOT USE 1/4" DIAMETER GLASS FUSES AS THEY ARE NOT SUITABLE FOR CONTINUOUS DUTY IN SIZES ABOVE 15 AMPS. Circuit breakers are very sensitive to high temperatures and will "false trip" when mounted in hot environments or operated close to their capacity.

#### FIG. 1



WIRE DESIGNATORS AND COLORS

1 - WHITE - MOMENTARY - DOWN

2 - ORANGE - MAINTAIN - UP

3 - YELLOW

4 - GREEN

5 - BLUF

6 - VOILET

7 - GRAY

8 - BLUE - LEVEL 1

9 - RED - LEVEL 2

10- WHITE - LEVEL 3

H - RED - MAIN POWER IN

G - BLACK - GROUND

B - RED - BACKLIGHTING

### WARRANTY

This product was tested and found to be operational at the time of manufacture. Provided this product is installed and operated in accordance with the manufacturer's recommendations, CODE 3, Inc. guarantees all parts and components except the lamps for a period of 1 year from the date of purchase or delivery, whichever is later. Units demonstrated to be defective within the warranty period will be repaired or replaced by the factory or at a factory authorized service center at no cost.

Use of a lamp or other electrical load of a wattage higher than installed or recommended by the factory causes this warranty to become void. Failure or destruction of the product resulting from abuse or unusual use and/or accidents is not covered by this warranty.

CODE 3, Inc. shall in no way be liable for other damages including consequential, indirect or special damages whether loss is due to negligence or breach of warranty.

CODE 3, INC. MAKES NO OTHER EXPRESS OR IMPLIED WARRANTY INCLUDING, WITHOUT LIMITATION, WARRANTIES OF FITNESS OR MERCHANTABILITY, WITH RESPECT TO THIS PRODUCT.

## PRODUCT RETURNS

In order to provide you with faster service, if you are going to return a product for repair or replacement\*, please contact our factory to obtain a Return Goods Authorization Number (RGA number) before you ship the product to CODE 3. Write the RGA number clearly on the package near the mailing label. Be sure you use sufficient packing materials to avoid damage to the product being returned while in transit.

\*CODE 3, Inc. reserves the right to repair or replace product at its discretion. CODE 3, Inc. assumes no responsibility or liability for

expenses incurred for the removal and/or reinstallation of products requiring service and/or repair.

NEED HELP? Call our Technical Assistance HOTLINE - (314) 996-2800

Code 3,® Inc., a subsidiary of Public Safety Equipment, Inc.



CODE 3<sup>®</sup>, Inc. 10986 N. Warson Road St. Louis, Missouri 63114-2029—USA Ph. (314) 426-2700 Fax (314) 426-1337 www.code3pse.com