IMPORTANT SAFETY INSTRUCTIONS



- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as the power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

IMPORTANT SAFETY CONSIDERATIONS FOR Door Window Sensor

- The apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- See label on bottom of unit for additional markings.

During Transportation to the Subscriber Home

• Do not expose the device to rain or moisture.

During Installation

- Do not place the device in an enclosed area where the cooling vents are blocked or impede the flow of air through the ventilation openings.
- Install the device so that its position does not interfere with its proper ventilation. For example, do not place the device on a bed, sofa, rug, or similar surface that could block the ventilation openings.
- Place the device on a flat surface not prone to vibration or impact.
- Do not place the device on top of another electronic device.
- Do not install the device in an area where condensation occurs.
- Installation and wiring methods shall be in accordance with the National Electrical Code, ANSI/NFPA 70
- Please make sure that the sensor and magnet is located less than 6 mm from each other. For optimal performance, it is highly
- Recommended to install the Door/Window sensor on the fixed frame and the magnet on the moving
 part of the door/window. Place the sensor near the top of the door that close to the opening edge of
 the door. This is the mounting location for the sensor.
- Use the provided double-sided tape on the sensor. Attach the sensor to the door. Press firmly and hold in place for a few seconds. Secure it with silicone if needed.
- Use provided double-sided tape on the magnet. Make sure the alignment of both sensor and magnet are facing each other.
- Press firmly and hold in place for a few seconds. Secure it with silicone if needed.

Federal Communication Commission Interference Statement

- FCC Statement: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:
- Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- The FCC ID for this device is P27SZDWS08
- You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.
- This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference, and

(2) This device must accept any interference received, including interference that may cause undesired operation.

FCC RF Radiation Exposure Statement:

This Transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

UL Statement: This device conforms to ANSI/UL STD 634

Industry Canada statement:

- Canada Statement: This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:(1)This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.
- Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage; (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le onctionnement.
- The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance. Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.
- Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être
- installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.