



Indoor Wi-Fi Security Camera

Installation Guide

ADC-V523

Before You Start



For additional instructions and tips, visit telus.com/IndoorCamera or scan the QR code.




What's in the box?



Indoor Camera
ADC-V523



Mounting Plate



Power Supply



Wall Anchors



Wall Screws



You'll need:



Smartphone or Tablet



2.5 Mbps Upload Wi-Fi

Optional



Drill



Screwdriver




Pencil



6mm (1/4 inch) Drill Bit

1

Select a Location




NOTE

For wall mounting installation steps see Step 8.

2

Check Your Wi-Fi Speed at Location



The Indoor Camera requires a minimum of 2.5 Mbps upload speed to operate. In a browser on your smartphone visit telus.com/speedtest to determine the Internet speed at your chosen location.





No Wi-Fi?


If you are unable to find a location with adequate Wi-Fi coverage, please contact TELUS for assistance.

3

Turn on Camera


**LED not flashing white?**

Press and hold the WPS/RESET button on the bottom of the device until the light starts flashing white.



4


Get the TELUS SmartHome App



Download the TELUS SmartHome app, then log in with your My TELUS credentials.



5

Add Camera to Your Account





6

Connect to Camera's Temporary Wi-Fi Network




7

Follow Steps in App




Solid



8

Optional: Wall Mount Installation

1 Attach Mounting Bracket




TIP
You can also attach the mounting bracket by drilling holes and using the drywall anchors provided.

6mm (1/4 inch) Drill Bit

Drywall Anchors

2 Adjust Camera




9

Calibrate Camera


**IMPORTANT**

Without completing this step, the Indoor Camera will not function properly.





3 Remove Inserts




4 Route Cable




5 Attach Camera







10

Customize Smart Video Alerts and Recording Rules



Nice Work, You're All Done!











Additional Support

Our customer support agents are available 24/7 at 1-855-255-8828.

For additional installation instructions, videos and troubleshooting, please visit telus.com/IndoorCamera or scan the QR code below.





LED Reference Guide

Off		Power off
Solid		Connected to TELUS SmartHome
Flashing		Local network connection
Flashing		Factory reset
Solid		No local or Internet connection
Flashing		Power on, camera booting
Flashing		WPS mode
Flashing		Wi-Fi access point mode

Troubleshooting

- If you have issues connecting the camera to a TELUS account, unplug the power cable from the camera and plug it back in.
- If issues persist, reset the camera to factory defaults and try again.



IMPORTANT
 If the camera was previously installed on a TELUS account, it will need to be deleted before it can be installed again.