



Automation Hub

Installation Guide

ADC-SG130Z

Before You Start



For additional instructions and tips, visit telus.com/AutomationHub or scan the QR code.




What's in the box?



Automation Hub



Ethernet Cable



Power Supply



You'll need:



Smartphone or Tablet



Existing Internet Modem


Optional



Network Switch




Ethernet Cable




Network Switch Power Supply

Overview



Ports
Ethernet
Power



LEDs


- Power
- Data
- Communication
- Wi-Fi
- Z-Wave




Buttons
Reset
WPS
Z-Wave

1

Locate Your Modem



Possible Locations




Unable to find your modem?

Modems come in different shapes and sizes. If you need help locating your modem, support agents are available 24/7 at 1-855-255-8828.

2

Connect to Modem



You'll need:



3



Connect Power

You'll need:



Alternative: Connect with Network Switch

You'll need:





NOTE

The Network Switch is only required if there are no available LAN ports on your existing modem. If you unplug a device to free up a port on your modem, make sure you plug that device into the Network Switch.


4

Booting Up



5


Get the TELUS SmartHome App



Download the TELUS SmartHome app, then log in with your My TELUS credentials.

6


Add Automation and Video Devices



Visit telus.com/SmartHomeGuides for instructions on installing your devices.


7

Add Device to Your Account



8

Return to Home Screen



Nice Work, You're All Done!



Additional Support

Our customer support agents are available 24/7 at
1-855-255-8828.

For additional installation instructions, videos and trouble-
shooting, please visit telus.com/SmartHomeGuides or
scan the QR code below.



LED Reference Guide

Power LED

Off		Device powered off
Solid		Device powered on
Flashing		Device booting

Data LED

Off		No data is being transferred over Ethernet
Solid		Device transferring or receiving data over Ethernet
Flashing		Device transferring or receiving data over Ethernet

Communication LED

Off		No local or Internet connection
Solid		Connected to TELUS SmartHome
Flashing (slow)		Local connection, no Internet
Flashing (5 quick blinks)		Communication test initiated

LED Reference Guide

Wi-Fi LED

Off		Inactive
Solid		Active
Flashing		WPS mode

Z-Wave LED

	(Add process)	(Remove process)
Off	Normal operation	
Flashing (slowly)	In Add mode	Device removed
Flashing (quickly)	Adding new device	
Solid (15 seconds)	Device added	In Remove mode

Additional states (All LEDs)

Flashing (escalating)		Firmware upgrade in progress
Flashing (simultaneously)		Reset in progress

Troubleshooting (Factory Reset)



NOTE

If you have issues connecting the device to a TELUS account, power cycle the Automation Hub (unplug the power cable from the Automation Hub and plug it back in to restore power). If issues persist, reset the device to factory defaults.

