

bella™ 4qt Slim Air Fryer

Quick Start Guide

1. Insert the crisping tray.



2. Insert the assemble basket into the front of the air fryer.



3. Plug in the unit and press the power button to turn on the unit.

WARNING: Keep appliance at least 4 inches away from walls or other objects during operation.



4. Select one of the desired preset options. The preset time and temperature will appear and alternate on the screen.



5. To adjust the air fryer temperature, press the TIME/TEMP button until you see the temperature displayed then press (-) or (+) until you reach the desired temperature.



NOTE:
To toggle between Fahrenheit and Celsius, press and hold the TIME/TEMP button and the (+) button at the same time for 5 seconds.

6. To adjust the air fryer time, press the TIME/TEMP button until you see the time displayed then press (-) or (+) until you reach the desired time.



7. Press START/STOP to begin cooking.



WARNING: This air fryer should not be used to boil water. This air fryer should not be used to deep fry food. Please read the detailed instructions provided in the instruction manual.