



Emergency Eyewash Station Checklist

11 Aug 2023 / Tyrese Kessler

Complete

Score	1 / 1 (100%)	Flagged items	1	Actions	1
Conducted on	11 Aug 2023 10:00 PST				
Inspected by	Tyrese Kessler				
Company/Site name	TBI Pharmaceuticals, Inc.				
Location	Wyoming, USA (43.0759678, -107.2902839)				

Flagged items & Actions

1 flagged, 1 action

Flagged items

1 flagged, 1 action

Eyewash Station Inspection / Visual Inspection

Is the eyewash station clearly labeled with appropriate signage and instructions for use?

Fail

Signages currently posted are outdated. The instructions also lack some steps that were recently added to our safety manuals. Endorsing this to our facility manager, Savanna Mills, for updating this weekend.



Photo 1

To do | Assignee: SafetyCulture Staff | Priority: Low | Due: 20 Aug 2023 17:00 PST | Created by: SafetyCulture Staff

Update signages and instructions on the emergency eyewash station.

Other actions

0 actions

Eyewash Station Inspection

1 flagged, 1 action, 1 / 1 (100%)

Visual Inspection

1 flagged, 1 action

Capture and upload media documentation of findings/results as applicable.

Is the eyewash station clearly labeled with appropriate signage and instructions for use?

Fail

Signages currently posted are outdated. The instructions also lack some steps that were recently added to our safety manuals. Endorsing this to our facility manager, Savanna Mills, for updating this weekend.



Photo 1

To do | Assignee: SafetyCulture Staff | Priority: Low | Due: 20 Aug 2023 17:00 PST | Created by: SafetyCulture Staff

Update signages and instructions on the emergency eyewash station.

Is the path to the eyewash station well-lit, clear of obstacles, and located within the required proximity to potential hazard areas?

Pass

Is the eyewash station clearly visible and demarcated?

Pass

Are there any electrical connections close to the eyewash or eyewash station?

Pass

Electrical connections aren't that close to the station and are well-organized to avoid electrical hazards and obstructions.

Does the station have all parts/not broken?

Pass

Is there a bucket located under the eyewash to collect runoff?

Pass

Are the eyewash nozzles free from clogs, debris, or any signs of damage?

Pass

Are caps damaged, need to be replaced, or need to be cleaned due to dirt and debris?

Pass

Activation Test

1 / 1 (100%)

Activate eyewash station to check for appropriate flow. Flush the eyewash for at least 30 seconds.

Does the eyewash station operate properly?

Pass

Are the jets working properly?	Pass
Is there a steady flow of water from both eye pieces?	Pass
If the flushing fluid is water, the water in the eyewash station shall be potable (drinkable) and kept at a tepid temperature not exceeding 38 degrees C (100 degrees F).	Pass
Is the water clear?	Pass
Do the caps open (pop off) without assistance when fully activated? If not, this is an indication of low flow.	Pass
Can the unit be activated without having to hold on (hands-free) and adjust the flow? Check that sufficient flushing height is provided (e.g., flow not trickling out).	Pass
Is the plumbing free from leakage?	Pass
Promptly clean up any water that is spilled on the floor as a result of the inspection process. Any water collected can be emptied at the most convenient location such as a sink, custodial floor sink, or a floor drain.	☒

Completion

Ensure all recommended corrective actions are appropriately assigned and endorsed before signing and completing the report.

Other Notes and Comments

Overall, the eyewash station is in good and proper working condition. Only the signage and instructions need urgent corrective action, which I already endorsed and assigned to our facility manager for updating this weekend. No other issues were found.

Inspector Name and Signature



Tyrese Kessler
11 Aug 2023 21:20 PST

Media summary



Photo 1