



# Check List for Scheduled Maintenance



Superbike

Customer Name:	Model:	Plate number:
Frame number (VIN):	Registration date:	Mileage:
Current date:	Work Order Number:	Service type:

## Scheduled Maintenance Check List for Superbike family

Check the boxes close to the performed service operations

Performed	Replaced		Time Service* 田		
			Mileage DESMO Service* ➤	Mileage OIL Service* ㉿	Mileage 1000 Service*
<input type="checkbox"/>	<input type="checkbox"/>	Reading of the error memory with DDS 3.0 and check of technical updates and recall campaigns on DCS	•	•	12
<input type="checkbox"/>	<input type="checkbox"/>	Change engine oil and filter	•	•	12
<input type="checkbox"/>	<input type="checkbox"/>	Check and clean air filter		•	12
<input type="checkbox"/>	<input type="checkbox"/>	Change air filter			•
<input type="checkbox"/>	<input type="checkbox"/>	Replace timing belts (848, 1098 and 1198 only)			•
<input type="checkbox"/>	<input type="checkbox"/>	Check and/or adjust valve clearance (848, 1098 and 1198 only)		•	•
<input type="checkbox"/>	<input type="checkbox"/>	Check and/or adjust valve clearance			•
<input type="checkbox"/>	<input type="checkbox"/>	Check secondary air system reeds (where available)			•
<input type="checkbox"/>	<input type="checkbox"/>	Replace spark plugs			•
<input type="checkbox"/>	<input type="checkbox"/>	Change coolant			•
<input type="checkbox"/>	<input type="checkbox"/>	Check the variable-length intake manifold system (VIS) using DDS 3.0 (Panigale V4 only)			•
<input type="checkbox"/>	<input type="checkbox"/>	Change front fork fluid			•
<input type="checkbox"/>	<input type="checkbox"/>	Visually check the front fork and rear shock absorber seals	•	•	12
<input type="checkbox"/>	<input type="checkbox"/>	Check clutch plate pack thickness (models with dry clutch only)			•
<input type="checkbox"/>	<input type="checkbox"/>	Replace clutch housing (models with dry clutch only)			Every 48,000 km/30,000 mi
<input type="checkbox"/>	<input type="checkbox"/>	Check brake and clutch fluid level	•	•	12
<input type="checkbox"/>	<input type="checkbox"/>	Change brake and clutch fluid			24
<input type="checkbox"/>	<input type="checkbox"/>	Check front and rear brake disc and pad wear		•	12
<input type="checkbox"/>	<input type="checkbox"/>	Check the proper tightening of front and rear brake calliper screws and front brake disc screws		•	12
<input type="checkbox"/>	<input type="checkbox"/>	Check the tightening of the rear brake disc screws (with removal of rear wheel shaft if rear brake disc screws with hexagon wrench flat are present)			•
<input type="checkbox"/>	<input type="checkbox"/>	Check front and rear wheel nuts and rear sprocket nut tightening		•	12
<input type="checkbox"/>	<input type="checkbox"/>	Check frame-to-engine, frame-to-swinging arm and frame-to-rear shock absorber fasteners tightening		•	12
<input type="checkbox"/>	<input type="checkbox"/>	Check tightening of RH tripod to rear bank fastener (Panigale V4 R only)			•
<input type="checkbox"/>	<input type="checkbox"/>	Check the wheel hub bearings		•	12
<input type="checkbox"/>	<input type="checkbox"/>	Check silentblocs on rear sprocket and lubricate the rear wheel shaft			•
<input type="checkbox"/>	<input type="checkbox"/>	Check chain, rear sprocket and sprocket wear and check final drive chain tension, lubrication and stretch. Measured stretch value: _____ (mm) <b>NOTE:</b> It is recommended to change the final drive chain kit within 20,000 km/12,000 mi.	•	•	12
<input type="checkbox"/>	<input type="checkbox"/>	Replace chain, sliding shoes, rear sprocket, front sprocket and swinging arm protection plate (only carbon swinging arm)			**
<input type="checkbox"/>	<input type="checkbox"/>	Check steering tube bearing clearance		•	12
<input type="checkbox"/>	<input type="checkbox"/>	Check the freedom of movement and tightening of the side stand	•	•	12
<input type="checkbox"/>	<input type="checkbox"/>	Check that all gaiters and visible hoses (i.e. fuel, brake and clutch, cooling system, bleed, drain hoses, etc.) are not cracked, are tight and properly housed	•	•	12
<input type="checkbox"/>	<input type="checkbox"/>	Check rear brake lever free play and handlebar lever and pedal control lubrication	•	•	12
<input type="checkbox"/>	<input type="checkbox"/>	Check tyre pressure and wear	•	•	12
<input type="checkbox"/>	<input type="checkbox"/>	Check the operation of all electric safety devices (side stand and clutch sensor, front and rear brake switch, engine stop switch, gear/neutral sensor)	•	•	12
<input type="checkbox"/>	<input type="checkbox"/>	Check lighting devices, turn indicators, horn and controls operation	•	•	12
<input type="checkbox"/>	<input type="checkbox"/>	Adjust exhaust butterfly valve opening Bowden cable using DDS 3.0 (Panigale V4 only)	•	•	12
<input type="checkbox"/>	<input type="checkbox"/>	Final test and road test of the motorcycle, testing safety devices (e.g. ABS and DTC), electric fans and idling	•	•	•
<input type="checkbox"/>	<input type="checkbox"/>	Visually check the coolant level and circuit for damage	•	•	•
<input type="checkbox"/>	<input type="checkbox"/>	Soft cleaning of the vehicle, service coupon registration with turning off of Service warning light on instrument panel with DDS 3.0 and filling in of the on-board documentation (Service Booklet)	•	•	•

\* The Mileage 1000 Service must be performed after the first 1,000km.  
 The Mileage OIL Service ㉿ must be performed every 12,000 km for the model versions 848/1098/1198/899 Panigale/959 Panigale/1199 Panigale/1299 Panigale/Panigale V2/Panigale V4.  
 The Mileage DESMO Service ➤ must be performed every 24,000 km for the model versions 848/1098/1198/899 Panigale/959 Panigale/1199 Panigale/1299 Panigale/Panigale V2/Panigale V4.  
 The Time Service 田 must be performed every 12 months.  
 \*\* Every 5,000 km for Superleggera 1299 and every 10,000 km for Panigale V4 R and Panigale V4 SP  
 NOTE: For the models 848/1098/1198/899 Panigale/959 Panigale/1199 Panigale and 1299 Panigale, in case of Mileage DESMO Service ➤ it is necessary to perform also a Mileage OIL Service ㉿.

Thank you! Your Ducati Technician: