
Nokia True Wireless Earbuds (BH-705) Quick Start Guide



What's in the box



USB-C Cable



Earbuds



Quick Start Guide




Ear Tips



x 1

Product overview



v	Ear tip
0	Multi-function button
€	LED indicator light
Ø	Microphone
Θ	Charging case
0	Right earbud charging status LED

Charging case battery status LED

Left earbud charging status LED

USB-C Port

Get started

1.Before using Nokia True Wireless Earbuds, place the earbuds in the charging case, then connect the USB-C cable to a power source to begin charging. Charge the earbuds and the charging case fully before the first use.



When you shake the charging case, the battery status LED flashes white to show the battery status:




Fully charged	;∳<	on
a < 75%	; • ;	x 4
a < 50%	; ф :	х 3
□ < 25%	; o :	x 2

The charging status LEDs of the right and left earbuds turn red when charging, and turn off when fully charged.



2.Press the right end to open the charging case. The charging case will stop the power supply to the earbuds at the same time.



For optimal fit and audio performance, replace the ear tips with the size that best suits you.






Pair and connect with Bluetooth

1.Pairing with the device:

Turning on and Pairing
When you take the earl


When you take the earbuds out from the charging case, the earbuds will turn on and pair with each other automatically. When they have successfully paired, both of the LED indicator lights will flash blue once and are then ready to connect with your Bluetooth® device.



During pairing, both of the LED indicator lights flash blue and red alternately.

Connecting with your Bluetooth device

Turn on Bluetooth in your device and choose "Nokia Earbuds" from the Bluetooth menu to connect.



During the connection process, the LED indicator light on the right earbud will flash blue and red alternately. The LED indicator lights of the earbuds will flash blue when they are successfully connected via Bluetooth, as illustrated below.

- After the pairing has been completed:
- The earbuds will automatically connect with your Bluetooth device when taken out of the charging case after the initial pairing.
- 3.The earbuds will automatically power off if there is no Bluetooth connection within 10 minutes.
- 4.The LED indicator light of the earbud will keep flashing red when it is low in battery power.



Using your earbuds

1.Buttons



Play or pause music*	₩ ×1
Next track	🕒 🕓 2 secs
Volume up	₩ ×2
Answer or end calls *	₩ x1
Reject ca ll s*	₩ x2
Activate voice commands	👆 + 🦫 🕓 1 sec



Previous track	🕒 🕓 2 secs
Vo l ume down	₩ x2

^{*}Function also works on the left earbud.

2.Additional controls:

a. Manually power on and off.



- "	
Power off	secs

b. Pair the left and right earbuds manually if the connection is lost.



c. Reset to the original settings:

Power off the earbuds > Press and hold the multifunction key for 8 seconds (the LED will flash blue and red alternately) > Press the multifunction key 2 times (the LED will flash blue and red once and power off automatically).

Product and safety information

Remote control functions may vary depending on the model of your device and application. Sound track instructions do not respond to iOS devices. Since devices with Bluetooth wireless technology communicate using radio waves, they do not need to be in direct line-of-sight. Bluetooth devices must, however, be within 10 meters (33 feet) of each other, although the connection may be subject to interference from obstructions such as walls or from other electronic devices.

- Frequency Band: 2400 MHz 2483 MHz
- Maximum Radio Frequency Power: -6~+4dBm

For your safety

A Important: Read these simple guidelines. Not following them may be dangerous or against local laws and regulations. For further info. read the complete user guide.



Switch off in restricted areas

Switch the device off when a Bluetooth headset use is not allowed or when it may cause interference or danger, for example, in aircraft, in hospitals or near medical equipment, fuel, chemicals, or blasting areas. Obey all instructions in restricted areas.



All wireless devices may be susceptible to interference, which could affect performance.



Batteries, chargers, and other accessories

Use only batteries, chargers, and other accessories approved by HMD Global Ov for use with this device. Do not connect incompatible products.



Protect your hearing

To prevent possible hearing damage, do not listen at high volume levels for long periods.

Hearing

Warning: When you use the headset, your ability to hear outside sounds may be affected. Do not use the headset where it can endanger your safety. The surface of this product is nickel-free.

Small children

Your device and its accessories are not toys. They may contain small parts. Keep them out of the reach of small children.

Take care of your device

Handle your device with care. The following suggestions help you keep your device operational.

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that corrode electronic circuits.
- Do not use or store the device in dusty or dirty areas.
- Do not store the device in high temperatures. High temperatures may damage the device or battery.
- Do not store the device in cold temperatures. When the device warms to its normal temperature, moisture can form inside the device and damage it.
- Do not open the device other than as instructed in the user guide.
- Do not drop, knock, or shake the device or the battery. Rough handling can break it.
- Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not paint the device. Paint can prevent proper operation.
- Do not put the device into the water.

Recycle

Always return your used electronic products, batteries, and packaging materials to dedicated collection points. This way you help prevent uncontrolled waste disposal and promote the recycling of materials.

Electrical and electronic products contain a lot of valuable materials, including metals (such as copper, aluminium, steel, and magnesium) and precious metals (such as gold, silver, and palladium). All materials of the device can be recovered as materials and energy.

Crossed-out wheelie bin symbol



The crossed-out wheeled bin symbol on your product, battery. literature, or packaging reminds you that all electrical and electronic products and batteries must be taken to separate collection at the end of their working life.

Do not dispose of these products as unsorted municipal waste: take them for recycling. For info on your nearest recycling point, check with your local waste authority.

Battery info

Your device has an internal, non-removable, rechargeable battery. Do not attempt to remove the battery, as you may damage the device. The battery can be charged and discharged hundreds of times, but it will eventually wear out. Charging time can vary depending on device capability.

Battery safety

If left unused, a fully charged battery will lose its charge over time. Always keep the battery between 15°C and 25°C (59°F and 77°F) for optimal performance. Extreme temperatures reduce the capacity and lifetime of the battery. A device may temporarily stop working if its battery is too hot or too cold.

Do not dispose of batteries in a fire as they may explode. Obey local regulations. Recycle when possible. Do not dispose as household waste. Use the battery for its intended purpose only, Improper use of, or use of unapproved or incompatible, batteries may present a risk of fire. explosion, or other hazard, and may invalidate any approval or warranty. If you believe the battery is damaged, take it to a service centre or your local shop before continuing to use it. Never use a damaged battery. Do not charge your device during a lightning storm.

Implanted medical devices

To avoid potential interference, manufacturers of implanted medical devices recommend a minimum separation of 15.3 centimetres (6 inches) between a wireless device and the implanted medical device. Persons who have such devices should:

- Always keep the wireless device more than 15.3 centimetres (6 inches) from the medical device
- Not carry the wireless device in a breast pocket.
- Switch the wireless device off if there is any reason to suspect that interference is taking place.
- Follow the manufacturer directions for the implanted medical device.

If you have any questions about using your wireless device with an implanted medical device, consult your health care provider.

Copyrights and other notices

The availability of products, features, apps, and services may vary by region. For more info, contact your dealer or your service provider. This device may contain commodities, technology or software subject to export laws and regulations from the US and other countries. Diversion contrary to law is prohibited.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. HMD Global reserves the right to revise this document or withdraw it at any time without prior notice. Reproduction, transfer or distribution of part or all of the contents in this document in any form without the prior written permission of HMD Global is prohibited. HMD Global operates a policy of continuous development, HMD Global reserves the right to make changes and improvements to any of the products described in this document without prior notice.

Manufacturer and importer in EU: HMD Global Ov, Karaportti 2, 02610

Espoo, Finland, HMD Global Privacy Policy, available at http://www.nokia.com/phones/ privacy, applies to your use of the device. In the unlikely event that this product is faulty, please return it to the store where you purchased it with your proof of purchase. For more information on this or other products please visit

www.nokia.com/phones.

© 2018 HMD Global, All rights reserved, HMD Global Ov is the exclusive licensee of the Nokia brand for phones & tablets. Nokia is a registered trademark of Nokia Corporation.

The Bluetooth word mark and logos are owned by the Bluetooth SIG. Inc. and any use of such marks by HMD Global is under license. All other trademarks are the property of their respective owners.

Declaration of Conformity

Hereby, HMD Global Oy declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU, A copy of the Declaration of Conformity can be found at : www.nokia.com/mobile-declaration-of-conformity.