

Seam Cleaner

PRODUCT DESCRIPTION

Used to clean exposed or contaminated seams prior to heat welding to remove any residual soap or revitalize aged membranes.

APPLICATION

- Do not use on "bag fresh" material that has been exposed for less than 12 hours unless it has been contaminated.
- Follow the guidance below for cleaning TPO:

Light Contamination

Membrane that has been exposed overnight or up to a few days to airborne debris, foot traffic, dew, or light precipitation can usually be cleaned with a white cloth moistened with EverGuard® TPO Cleaner. Be sure to wait for solvent to flash off prior to welding.

Dirt-Based Contamination

Membrane that is dirt encrusted will require the use of a low-residue cleaner, such as Formula 409®, and a mildly abrasive scrubbing pad to remove the dirt. This must be followed by cleaning with a white cloth moistened with EverGuard® TPO Cleaner. Be sure to wait for solvent to flash off prior to welding.

Exposure-Based Contamination

Membrane that is weathered or oxidized will require the use of EverGuard® TPO Cleaner and a mildly abrasive scrubbing pad to remove the weathered / oxidized top surface layer. This must be followed by cleaning with a white cloth moistened with EverGuard® TPO Cleaner. Unexposed membrane left in inventory for a year or more may need to be cleaned as instructed above. Be sure to wait for solvent to flash off prior to welding.

- VOC Content of 861 grams/liter.



PRODUCT INFORMATION

Can size	100 lineal ft./pt.
Cans per carton	<454 g/L
Weight per case	Clear and white
Cases per pallet	<454 g/L
Product SKU	Clear and white

In view of innovation, the specifications are subject to change without any prior notice and in the event of such changes, BMI shall ensure that the new specifications are equivalent if not better.