

## How to Replace Batteries in a 2GIG Fob Model 2GIG-KEY2-345

### Description

---

This page shows battery replacement for 2GIG Fob Model 2GIG-KEY2-345



Because there are many different versions of fobs, it is important to remove the sensor cover first to determine what kind of batteries are required for your equipment. We advise you to check before purchasing batteries.

### Preparation

---

**\*\*\*IMPORTANT customers who use myadt.ca\*\*\*** Before removing the sensor, place the panel on test mode through [myadt.ca](https://myadt.ca). After logging in:

1. Tap **[Home]**
2. Tap **[Place on Test]**
3. Enter your expiration date and time
4. Enter your password
5. Tap **[Yes-Proceed]**

### Parts Required

---

- One CR2025 battery

- A Phillips screwdriver
- A small flathead screwdriver

## Instructions

---

1. Flip the fob over and remove the small phillips screw located at the bottom center of the fob
  - a. Ensure to place the screw where it will not be lost
2. Remove the back of the fob
3. Pull the battery out of the battery clip
4. Place the new batteries into the battery clip
5. Place the back cover back onto the fob
6. Reposition the screw to re-secure the back cover
7. Arm and disarm the panel with the use of the fob

**\*\*\*If the low battery alert does not clear or if the panel shows sensor tamper, walk through the steps above once more. It could be either the batteries or the keyfob cover not on properly\*\*\***